



Modbus RTU Option Card for VLT 5000/6000 Adjustable Frequency Drive



DANGER

Rotating shafts and electrical equipment can be hazardous. Perform all electrical work in conformance with the National Electrical Code (NEC) and all local regulations. Installation, start-up and maintenance should be performed only by qualified personnel.

Factory recommended procedures, included in this manual, should be followed. Always disconnect electrical power before working on the unit.

Although shaft couplings or belt drives are generally not furnished by the manufacturer, rotating shafts, couplings and belts must be protected with securely mounted metal guards that are of sufficient thickness to provide protection against flying particles such as keys, bolts and coupling parts. Even when the motor is stopped, it should be considered “alive” as long as its controller is energized. Automatic circuits may start the motor at any time. Keep hands away from the output shaft until the motor has completely stopped and power is disconnected from the controller.

Motor control equipment and electronic controls are connected to hazardous line voltages. When servicing drives and electronic controls, there will be exposed components at or above line potential. Extreme care should be taken to protect against shock. Stand on an insulating pad and make it a habit to use only one hand when checking components. Always work with another person in case of an emergency. Disconnect power whenever possible to check controls or to perform maintenance. Be sure equipment is properly grounded. Wear safety glasses whenever working on electric control or rotating equipment.

Safety Guidelines

1. The drive must be disconnected from the AC line before any service work is done.
2. The “Stop/Off” key on the local control panel of the drive does not disconnect the equipment from the AC line and is not to be used as a safety switch.

3. Correct protective grounding of the equipment must be established. The user must be protected against supply voltage and the motor must be protected against overload in accordance with applicable national and local regulations.
4. Ground currents are higher than 3 mA.

Warnings Against Unintended Start

1. While the drive is connected to the AC line, the motor can be brought to a stop by means of external switch closures, serial bus commands or references. If personal safety considerations make it necessary to ensure that no unintended start occurs, these stops are not sufficient.
2. During programming of parameters, the motor may start. Be certain that no one is in the area of the motor or driven equipment when changing parameters.
3. A motor that has been stopped may start unexpectedly if faults occur in the electronics of the drive, or if an overload, a fault in the supply AC line or a fault in the motor connection or other fault clears.
4. If the “Local/Hand” key is activated, the motor can only be brought to a stop by means of the “Stop/Off” key or an external safety interlock.

NOTE

It is responsibility of user or person installing drive to provide proper grounding and branch circuit protection for incoming power and motor overload according to National Electrical Code (NEC) and local codes.

The Electronic Thermal Relay (ETR) is UL listed. VLTs provide Class 20 motor overload protection in accordance with the NEC in single motor applications, when parameter 117 is set for “ETR TRIP 1”, “ETR TRIP 2”, “ETR TRIP 3”, or “ETR TRIP 4”, and parameter 105 is set for rated motor (nameplate) current.

DANGER

Touching electrical parts may be fatal – even after equipment has been disconnected from AC line. To be sure that capacitors have fully discharged, wait 14 minutes for 220 and 500 V units, wait 30 minutes for 550-600 V units after power has been removed before touching any internal component.

Table of Contents

Overview

Introduction	4
About This Manual	4
Assumptions	4
What You Should Already Know	4
Modbus Overview	5

Pre-installation Option Card and Drive Settings

Modbus RTU Option Card Baud Rate and Parity Settings	7
Modbus RTU Option Card Address Settings	8
VLT Parameter Settings	8

Installation of Modbus Option Card

Modbus RTU Option Card Environmental Requirements	9
Installation	9
Status LEDs	13
Option Card Operability Loop Back Test	13

Network Configuration

Remote Terminal Unit	14
Modbus Message Structure	14
Translation from Modbus RTU Protocol to FC Protocol	16
Memory Mapping	17
Message Translation Examples	20

Exception Codes

Exception Code Tables	24
-----------------------------	----

Appendix A

Supported Modbus Function Codes	25
---------------------------------------	----



Introduction

This manual provides comprehensive instructions on the installation and set up of the Modbus RTU option card for the VLT 5000 and VLT 6000 Adjustable Frequency Drives to communicate over a Modbus network.

For specific information on installation and operation of the adjustable frequency drive, refer to the *VLT Operating Instructions*.

About This Manual

This manual is intended to be used for both instruction and reference. It only briefly touches on the basics of the Modbus RTU protocol whenever necessary to gain an understanding of the Modbus RTU option card for the VLT.

experienced Modbus programmer, it is suggested that you read this manual in its entirety before you start programming since important information can be found in all sections.

This manual is also intended to serve as a guideline when you specify and optimize your communication system. Even if you are an

Assumptions

This manual assumes that you have a controller that supports the interfaces in this document and that all the requirements stipulated in the controller, as well as the

VLT 5000/6000 Adjustable Frequency Drive, are strictly observed, along with all limitations therein.

What You Should Already Know

The VLT Modbus RTU option card is designed to communicate with any controller that supports the interfaces defined in this

document. It is assumed that you have full knowledge of the capabilities and limitations of the controller.

Modbus RTU Overview

The common language used by all Modicon controllers is the Modbus RTU protocol. This protocol defines a message structure that controllers will recognize and use, regardless of the type of networks over which they communicate. It describes the process a controller uses to request access to another device, how it will respond to requests from the other devices, and how errors will be detected and reported. It establishes a common format for the layout and contents of message fields.


During communications on a Modbus RTU network, the protocol determines how each controller will know its device address, recognize a message addressed to it, determine the kind of action to be taken, and extract any data or other information contained in the message. If a reply is required, the controller will construct the reply message and send it.

Controllers communicate using a master-slave technique in which only one device (the master) can initiate transactions (called

'queries'). The other devices (slaves) respond by supplying the requested data to the master, or by taking the action requested in the query.

The master can address individual slaves, or can initiate a broadcast message to all slaves. Slaves return a message (called a 'response') to queries that are addressed to them individually. Responses are not returned to broadcast queries from the master.

The Modbus RTU protocol establishes the format for the master's query by placing into it the device (or broadcast) address, a function code defining the requested action, any data to be sent, and an error-checking field. The slave's response message is also constructed using Modbus protocol. It contains fields confirming the action taken, any data to be returned, and an error-checking field. If an error occurred in receipt of the message, or if the slave is unable to perform the requested action, the slave will construct an error message and send it in response.



VLT Modbus RTU Option Card

Modbus RTU Option Card Baud Rate and Parity Settings

The Modbus communication protocol accesses the internal VLT Danfoss FC protocol to control the drive through serial communications. The Modbus-to-FC interface uses 9600 Baud, 8 Bits, Even Parity, 1 Stop Bit.


The Modbus option card has a baud rate and parity 8-input dip switch. For Modbus networks operating with Modbus-to-FC properties, set switch positions in accordance with the following instructions. For Modbus networks operating at other than with Modbus-to-FC properties, determine switch positions from the tables provided below.

- Ensure that inputs 1-3 are set to ON (default setting) to select the 9600 baud rate.
- Ensure that inputs 4 and 5 are set to ON (default setting) to select even parity.

Switches 6-8 are unassigned reserved switches. Their setting does not matter.

NOTE

Set baud rate and parity switch settings prior to installing Modbus RTU option card for ease of access.



Baud Rate and Parity Switch

Communication Configuration	Baud Rate			Parity		Reserved		
	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
Default	ON	ON	ON	ON	ON	N/A	N/A	N/A
9600, 8N	ON	ON	ON	ON	ON	N/A	N/A	N/A
4800, 8O	OFF	ON	ON	OFF	ON	N/A	N/A	N/A
19200, 8E	ON	OFF	ON	OFF	OFF	N/A	N/A	N/A

Baud Rate	SW1	SW2	SW3
300	OFF	OFF	OFF
1200	OFF	OFF	ON
2400	OFF	ON	OFF
4800	OFF	ON	ON
9600	ON	OFF	OFF
19200	ON	OFF	ON
9600	ON	ON	OFF
9600	ON	ON	ON

Parity	SW4	SW5
N	ON	X
O	OFF	ON
E	OFF	OFF



Modbus RTU Option Card Network Address Settings

The Modbus RTU option card has an address and termination 9-input dip switch. The Modbus network address for the VLT is set by dip switch positions on the switch. Pin 9 is an ON/OFF switch for network termination. DIP switch positions are read on power-up only, so position changes will not be recognized until the next power-up.

- Set the Modbus address for the VLT in accordance with the table below. The default input setting is for ADDRESS 1 and termination ON.



Address and Termination

Address (Hex)	SW1 2^0	SW2 2^1	SW3 2^2	SW4 2^3	SW5 2^4	SW6 2^5	SW7 2^6	SW8 2^7	TERM
Default 01	ON	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON
55	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON
AA	OFF	ON	OFF	ON	OFF	ON	OFF	ON	ON
F7	ON	ON	ON	OFF	ON	ON	ON	ON	ON

Address Input Selection

VLT Parameter Settings

The Modbus RTU option card interface to the VLT 5000 and VLT 6000 Adjustable Frequency Drive FC protocol requires drive parameter values selected as shown. They are the default settings for those parameters and probably require no change to operate the drive using Modbus. The Modbus RTU option card always transmits to the drive in which it resides as address one (001). See the *VLT Operating Instructions* for details on selecting and changing parameter values, if necessary.

VLT 5000

- Parameter 500, *Address*: 001
- Parameter 501, *Baud Rate*: 9600 baud

VLT 6000

- Parameter 500, *Protocol*: FC protocol
- Parameter 501, *Address*: 001
- Parameter 502, *Baud Rate*: 9600 baud

Modbus RTU Option Card Environmental Requirements

Environmental requirements for the Modbus option card are listed below.

Description	Requirement
Operating temperature	-5° F to +140° F (-20° C to +60° C)
Storage temperature	-40° F to +176° F (-40° C to + 80° C)
Humidity	5% to 95% relative, non-condensing

Installation

The following section describes the installation procedures for the Modbus RTU option card. For additional information on installation and operation of the VLT, refer to the *VLT Operating Instructions*.

DANGER

VLT adjustable frequency drive contains dangerous voltages when connected to line voltage. After disconnecting from power line, wait at least 14 minutes for 220 and 500 V units, for 550-600 V units wait at least 30 minutes before touching any electrical components.

WARNING

Only a competent electrician should carry out electrical installation. Improper installation of motor or VLT can cause equipment failure, serious injury or death. Follow this manual, National Electrical Codes and local safety codes.

CAUTION

Electronic components of VLT adjustable frequency drive and Modbus option card are sensitive to electrostatic discharge (ESD). ESD can reduce performance or destroy sensitive electronic components. Follow proper ESD procedures during installation or servicing to prevent damage.

CAUTION

It is responsibility of user or installer of VLT adjustable frequency drive to provide proper grounding and motor overload and branch protection according to National Electrical Codes and local codes.




1. Access to Control Card Cassette

IP20/NEMA 1 Drives:

- Remove Local Control Panel (LCP) by pulling out from top of display (A) by hand. LCP connector on panel back will disconnect.
- Remove protective cover by gently prying with a screw driver at notch (B) and lift cover out of guide pin fittings.


IP54/NEMA 12 Drives:

- Open front panel of drive by loosening captive screws and swing open.
- Disconnect Local Control Panel (LCP) cable.



2. Disconnect Control Card Cassette

- Remove control wiring by unplugging connector terminals (A).
- Remove grounding clamps (B) by removing two screws holding each in place. Save screws for reassembly.
- Loosen two captive screws (C) securing cassette to chassis.




3. Remove Cassette and Ribbon Cables

- Lift control card cassette from bottom.
- Unplug two ribbon cables (A) and (B) from VLT control board.
- Unhinge cassette at top to remove.


NOTE

Ribbon cables will need to be reconnected to same connections from which removed.



4. Secure Modbus RTU Option Card

- On back of cassette, insert edge of Modbus RTU option card into slot at side of cassette (A).
- Secure opposite side of card with 2 self-tapping screws provided (B).




5. Wire Modbus RTU Option Card Connector to VLT Terminals

NOTE

Use 0.5 to 1.00mm² Cable (18 to 22 AWG). Torque terminals to 0.5-0.6 Nm (5 in-lbs). Modbus RTU interface connector terminals 5 and 6 are spares.

- Wire Modbus interface connector (24 V power) pin 1 to VLT terminal 12 or 13.
- Wire Modbus interface connector (RTxD+) pin 2 to VLT terminal 69.
- Wire Modbus interface connector (com) pin 3 to VLT terminals 20 and 61.
- Wire Modbus interface connector (RTxD-) pin 4 to VLT terminal 68.
- Plug Modbus interface connector into bottom of Modbus option card.




6. Install Ribbon Cables

NOTE

Ribbon cables must be reconnected to same connections from which removed.

- Connect control card cassette to hinge at top of drive.
- Connect ribbon cables.





7. Install Control Card Cassette


- Fasten control card cassette by alternately tightening two captive screws (A).
- Route control wires through clamp fasteners (B) and secure clamps with two screws.
- Connect control terminals (C) by firmly pressing them into connector receptacles.

IP20/NEMA 1 Drives

- Install LCP by sliding bottom into guide slots on cradle, then press into place ensuring that connector on back of LCP is engaged.
- Replace protective cover by positioning guide pins at bottom of cover into holes in bottom of chassis and snap top of cover into place.

IP54/NEMA 12 Drives

- Plug cable from LCP into connector on main control card.




8. Plug in Terminal Connector

- Connect Modbus signal wire (RTxD+) to pin 1 of RS-485 terminal block.
- Connect Modbus signal wire (Com) to pin 2 of RS-485 terminal block.
- Connect Modbus signal wire (RTxD-) to pin 3 of RS-485 terminal block.
- Plug RS-485 terminal block into connector at right side of Modbus option card.

IP54/NEMA 12 Drives

- Close front cover panel and fasten with captive screws.



Pin 1


RS-485 Connector

Status LEDs

The Modbus RTU option card has two LEDs. One LED is used as a status for Modbus communications and the other as a status for VLT drive communications. Both LEDs use the same communications patterns. On power up, each LED state is flashed on for 250 milliseconds (Red, Green, Orange, Off). The VLT LED powers up first, then the Modbus

LED. After power up, the following are the only valid states:

- Flashing Green (1 Hz): Communications online (VLT LED) or receiving data (Modbus LED)
- Flashing Red (1 Hz): Communications time out
- Solid Red: Major fault, communications halted



Option Card Operability Loop Back Test

A loop back test to confirm Modbus RTU option card operability can be performed. The option card must be removed from the adjustable frequency drive to gain access to the 8-input dip switch for baud rate and parity and to rewire the option card connectors.

⚠ DANGER

Ensure that power has been removed from adjustable frequency drive for a minimum of 14 minutes for 220 and 500 V units and 30 minutes for 550-600 V units to allow voltage to dissipate.

- Remove the option card in accordance with the procedures described in the installation section of this manual.
- Set the dip switch positions in accordance

with the table below.

- Remove all wiring from both the 6-pin option card connector and the 3-pin RS-485 connector.
- Wire the 6-pin option card connector to the 3-pin RS-485 connector as described below.

6-Pin Connector		RS-485 Connector
Pin 2	to	Pin 3
Pin 3	to	Pin 2
Pin 4	to	Pin 1

- Apply power to the unit.

After the normal status LED check at power-up (see Status LEDs), the loop back test sets both LEDs to orange for a successful test and red if the test fails.

SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
ON	ON	ON	OFF	OFF	ON	ON	ON

Loop Back Test Switch Positions



Remote Terminal Unit

The controllers are setup to communicate on the Modbus network using RTU (Remote Terminal Unit) mode, with each 8-bit byte in a

message contains two 4-bit hexadecimal characters. The format for each byte is shown below.

Coding System:	8-bit binary, hexadecimal 0-9, A-F Two hexadecimal characters contained in each 8-bit field of the message
Bits Per Byte:	1 start bit 8 data bits, least significant bit sent first 1 bit for even/odd parity; no bit for no parity 1 stop bit if parity is used; 2 bits if no parity
Error Check Field:	Cyclical Redundancy Check (CRC)

Modbus Message Structure

A Modbus message is placed by the transmitting device into a frame with a known beginning and ending point. This allows receiving devices to begin at the start of the message, read the address portion, determine which device is addressed (or all devices, if the message is broadcast), and to know when the message is completed. Partial messages are detected and errors set as a result.

The allowable characters transmitted for all fields are hexadecimal 0-9, A-F. The adjustable frequency drives monitor the network bus continuously, including 'silent' intervals. When

the first field (the address field) is received, each drive or device decodes it to determine whether it is the addressed device.

Modbus messages addressed to zero are converted to broadcast messages using the FC protocol. No response is needed on broadcast messages.

To ensure the attribute data returned is the most current, each attribute access must include one attribute only.

A typical message frame is shown below.

Start	Address	Function	Data	CRC Check	End
T1-T2-T3-T4	8 Bits	8 Bits	n x 8 Bits	16 Bits	T1-T2-T3-T4

Typical Modbus Message Structure

Modbus Message Structure (continued)

Start/Stop Field

Messages start with a silent interval of at least 3.5 character times. This is implemented as a multiple of character times at the 9600 network baud rate (shown as Start T1-T2-T3-T4). The first field then transmitted is the device address. Following the last transmitted character, a similar interval of at least 3.5 character times marks the end of the message. A new message can begin after this interval.

The entire message frame must be transmitted as a continuous stream. If a silent interval of more than 1.5 character times

occurs before completion of the frame, the receiving device flushes the incomplete message and assumes that the next byte will be the address field of a new message.

Similarly, if a new message begins earlier than 3.5 character times following a previous message, the receiving device will consider it a continuation of the previous message. This will set an error, since the value in the final CRC field is not valid for the combined messages.

Modbus Message Structure (continued)

Address Field

The address field of a message frame contains 8 bits. Valid slave device addresses are in the range of 0 – 247 decimal. The individual slave devices are assigned addresses in the range of 1 – 247. (0 is reserved for broadcast mode, which all slaves recognize.) A master addresses a slave by placing the slave address in the address field of the message. When the slave sends its response, it places its own address in this address field to let the master know which slave is responding.

Function Field

The function field of a message frame contains 8 bits. Valid codes are in the range of 1 – 255 decimal. (See Appendix A for a description of supported Modbus functions.) When a message is sent from a master to a slave device, the function code field tells the slave what kind of action to perform.

When the slave responds to the master, it uses the function code field to indicate either a normal (error-free) response, or that some kind of error occurred (called an exception response). For a normal response, the slave simply echoes the original function code. For an exception response, the slave returns a code that is equivalent to the original function code with its most-significant bit set to a logic 1. In addition, the slave places a unique code into the data field of the response message. This tells the master what kind of error occurred, or the reason for the exception. See the *Exception Codes* section in this manual for definitions.

Data Field

The data field is constructed using sets of two hexadecimal digits, in the range of 00 to FF hexadecimal. These are made from one RTU character. The data field of messages sent from a master to slave device contains additional information which the slave must use to take the action defined by the function code. This can include items like discrete and register addresses, the quantity of items to be handled, and the count of actual data bytes in the field. The data field can have a length of zero.

CRC Check Field

Messages include an error-checking field that is based on a cyclical redundancy check (CRC) method. The CRC field checks the contents of the entire message. It is applied regardless of any parity check method used for the individual characters of the message. The CRC value is calculated by the transmitting device, which appends the CRC as the last field in the message. The receiving device recalculates a CRC during receipt of the message and compares the calculated value to the actual value received in the CRC field. If the two values are not equal, an error results.

The error checking field contains a 16-bit binary value implemented as two 8-bit bytes. When this is done, the low-order byte of the field is appended first, followed by the high-order byte. The CRC high-order byte is the last byte sent in the message.

Coil/Register Addressing

All data addresses in Modbus messages are referenced to zero. The first occurrence of a data item is addressed as item number zero. For example:

The coil known as 'coil 1' in a programmable controller is addressed as coil 0000 in the data address field of a Modbus message. Coil 127 decimal is addressed as coil 007E_{HEX} (126 decimal).

Holding register 40001 is addressed as register 0000 in the data address field of the message. The function code field already specifies a 'holding register' operation. Therefore, the '4XXXX' reference is implicit. Holding register 40108 is addressed as register 006B_{HEX} (107 decimal).



Translation from Modbus RTU Protocol to FC Protocol

Refer to *Serial Communication for FC Protocol* in the *VLT Operating Instructions* for details on the Danfoss FC protocol used for Modbus serial communication within the VLT 5000/VLT 6000 Adjustable Frequency Drive.

Parameter Block

PKE

PKE contains AK with the parameter commands and replies, and PNU with the parameter number. The AK value is determined by the Modbus function code. Coil 65 decimal determines whether data written to the drive are stored in EEPROM and RAM (coil 65 = 1) or just RAM (coil 65 = 0). PNU is translated from the register address contained in the Modbus read/write message. The parameter number is translated to Modbus as (10 x parameter number)_{DECIMAL}.

IND

IND contains the index. The index is used, together with the parameter number, for read/write access. Index has 2 bytes – a low byte and a high byte. However, only the low byte is used for indexing. The high byte is used for reading and writing text. IND is set by a register in Modbus (40001_{HEX}). IND must be cleared by the Modbus master after reading/writing text.

PWE_{HIGH}/PWE_{LOW}

PWE contains the parameter value. The parameter value block consists of 2 words (4 bytes). The value depends on the command given (AK). PWE is zero filled on reads. On writes, PWE is filled with the data field of the Modbus write message.

PCD₁/PCD₂

PCD contains the process word block. The parameter value block consists of 2 words (4 bytes). The process word block is divided into two blocks of 16 bits and is stored in Modbus as status coils. The mapping of the PCD is shown below.

Process Block Updates

Upon every write to the PCD coils, the process block is written to the drive and returned from the drive. On parameter reads and writes, the PCD is deactivated on messages from the Modbus option card to the drive. The PCD coils are updated on response messages from the drive to the Modbus option card.

Text Blocks

Parameters stored as text strings are accessed the same as the other parameters except PWE is replaced with the text block. The maximum text block size is 20 characters. If a read request for a parameter is for more characters than the parameter stores, the response is space filled. If the read request for a parameter is for less characters than the parameter stores, the response is truncated.

	PCD ₁	PCD ₂
Control packet (master → slave)	Control word (Coils 1 – 16) _{DEC}	Reference value (Coils 17 – 32) _{DEC}
Reply packet (slave → master)	Status word (Coils 33 – 48) _{DEC}	Given output frequenc (Coils 49 – 64) _{DEC}

PCD Mapping

FC Protocol Control Word Bit Descriptions

Control Word Bit Descriptions

Bit	Setting	0	1
00	0	Preset Ref. LSB	
01	0	Preset Ref. MSB	
02	1	DC Brake	no DC Brake
03	0	Coast Sto	no Coast Stop
04	1	"Quick" Stop	no "Quick" Sto
05	1	Freeze Freq.	no Freeze Freq.
06	0	Ramp Stop	Start
07	0	no Reset	Reset
08	0	no Jo	Jog
09	0	no function	
10	1	Data Not Valid	Data Valid
11	0	Relay 1 OFF	Relay 1 ON
12	0	Relay 2 OFF	Relay 2 ON
13	0	Setup LSB	
14	0	Setup MSB	
15	0	no Reversing	Reversing

Conversion Factor

Conversion

The different attributes for each parameter can be seen in the section on factory settings. Since a parameter value can only be transferred as a whole number, a conversion factor must be used to transfer decimals.

Example:

Parameter 201: *Minimum Frequency*, conversion factor 0.1. If parameter 201 is to be set to 10 Hz, a value of 100 must be transferred, since a conversion factor of 0.1 means that the transferred value will be multiplied by 0.1. A value of 100 will, therefore, be understood as 10.0.

Index	Factor
74	3.6
2	100.0
1	10.0
0	1.0
-1	0.1
-2	0.01
-3	0.001
-4	0.0001

Memory Mapping

Parameter Values

Standard Data Types

Standard data types are int16, int32, uint8, uint16 and uint32. They are stored as 4x registers (40001 – 4FFFF). The parameters are read using function 03_{HEX} "Read Holding Registers." Parameters are written using function 6_{HEX} "Preset Single Register" for 1 register (16 bits), and function 10_{HEX} "Preset Multiple Registers" for 2 registers (32 bits). Valid sizes to read are 1 register (16 bits) and 2 registers (32 bits).

Nonstandard Data Types

Nonstandard data types are text strings and are stored as 4x registers (40001 – 4FFFF). The parameters are read using function 03_{HEX} "Read Holding Registers" and written using function 10_{HEX} "Preset Multiple Registers." Valid sizes to read are 1 register (2 characters) through 10 registers (20 characters). See *Text Blocks* section in this manual for truncation/space fill rules. IND (Modbus Register 1) must be written with a value of 0400_{HEX} (read) or 0500_{HEX} (write) prior to reading or writing a text string.



Memory Mapping (continued)

Status Coils Map (128 coils total)

Address (Decimal)	Description
1 – 16	PCD ₁ Control word (master → slave)
17 – 32	PCD ₂ Reference value (master → slave)
33 – 48	PCD ₁ Status word (slave → master)
49 – 64	PCD ₂ Given output frequency (slave → master)
65	Write memory storage type bit (used with AK), see PKE
66 – 128	Reserved

Memory Mapping (continued)

VLT 5000 Register Maps (65536 registers total)

Address (Decimal)	Description
00001	IND (index word)
00002	Modbus Communications Timeout Value (10 millisecond units)
00003	Drive Communications Timeout Value (10 millisecond units)
00004 – 00009	Reserved
00010	Parameter 001, Language
↓	↓
00190	Parameter 019, Operating State at Power-up, Local Control
00200 – 09999	Reserved
01000	Parameter 100, Configuration
↓	↓
01310	Parameter 131, Initial Voltage
01320 – 01999	Reserved
02000	Parameter 200, Output Frequency Range/Direction
↓	↓
02340	Parameter 234, Motor Phase Monitor
02350 – 02999	Reserved
03000	Parameter 300, Terminal 16, Digital Input
↓	↓
03460	Parameter 346, Encoder Loss Function
03470 – 03999	Reserved
04000	Parameter 400, Brake Function
↓	↓
04540	Parameter 454, Dead Time Compensation
04550 – 04999	Reserved
05000	Parameter 500, Address
↓	↓
05410	Parameter 541, Data Readout: Warning Word 2
05420 – 05999	Reserved
06000	Parameter 600, Operating Data: Operating Hours
↓	↓
06310	Parameter 631, Nameplate: Communication Option Ordering No.
06320 – 06999	Reserved
07000	Parameter 700, Relay 6, Output Function
↓	↓
07090	Parameter 709, Relay 9, Off Delay
07100 – 65536	Reserved

Memory Mapping (continued)

VLT 6000 Register Maps (65536 registers total)

Address (Decimal)	Description
00001	IND (index word)
00002	Modbus Communications Timeout Value (10 millisecond units)
00003	Drive Communications Timeout Value (10 millisecond units)
00004 – 00009	Reserved
00010	Parameter 001, Language
↓	↓
00170	Parameter 017, Operating State at Power-up
00180 – 09999	Reserved
01000	Parameter 100, Configuration
↓	↓
01170	Parameter 117, Motor Thermal Protection
01180 – 01999	Reserved
02000	Parameter 200, Output Frequency Range
↓	↓
02280	Parameter 228, Warning: High Feedback
02290 – 02999	Reserved
03000	Parameter 300, Terminal 16 Digital Input
↓	↓
03280	Parameter 328, Pulse Feedback, Max. Freq.
03290 – 03999	Reserved
04000	Parameter 400, Reset Function
↓	↓
04270	Parameter 427, PID Lowpass Filter Time
04280 – 04999	Reserved
05000	Parameter 500, Protocol
↓	↓
05660	Parameter 566, FLN Time Function
05670 – 05999	Reserved
06000	Parameter 600, Operating Data: Operating Hours
↓	↓
06310	Parameter 631, Nameplate: Communication Option Ordering No.
06320 – 06999	Reserved
07000	Parameter 700, Relay 6, Output Function
↓	↓
07110	Parameter 711, Relay 9, Off Delay
07120 – 65536	Reserved



Message Translation Examples

EXAMPLE ONE: Start Motor, Run Speed 40%

Modbus function 0F_{HEX} (*Force Multiple Coils*).

Message sent to Modbus RTU option card from Modbus master

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
Slave Address	Function	Coil Addr HI	Coil Addr LO	# of Coils HI	# of Coils LO	Byte Count	Force Data HI Coils (0-7)
01	0F	00	00	00	20	04	7C

Byte 8	Byte 9	Byte 10	Byte 11
Force Data LO Coils (8-15)	Force Data HI Coils (1 -23)	Force Data LO Coils (2 -31)	Error Check
04	99	19	[37] [43]

Modbus message string:

[01] [0F] [00] [00] [00] [20] [04] [7C] [04] [99] [19] [37] [43]

Start Command: 0000010001111100 = 047C_{HEX} (reversed)
(see *FC Protocol Control Word Bit Descriptions*)

Modbus message string:

[01] [0F] [00] [00] [00] [20] [04] [7C] [04] [99] [19] [37] [43]

NOTE: Speed Command: 4000_{HEX} = 100% speed
40% of 4000_{HEX} = 1999_{HEX} (reversed)

Message returned to Modbus master from Modbus RTU option card

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6
Slave Address	Function	Coil Addr HI	Coil Addr LO	No. of Coils HI	No. of Coils LO	Error Check
01	0F	00	00	00	20	[54] [13]

All values are in hexadecimal.

Message Translation Examples (continued)

EXAMPLE TWO: Ramp Stop Motor

Message sent to Modbus RTU option card from Modbus master

Byte 0 Slave Address	Byte 1 Function	Byte 2 Coil Addr HI	Byte 3 Coil Addr LO	Byte 4 # of Coils HI	Byte 5 # of Coils LO	Byte 6 Byte Count	Byte 7 Force Data HI Coils (0-7)
01	0F	00	00	00	20	04	3C

Byte 8 Force Data LO Coils (8-15)	Byte 9 Force Data HI Coils (1 -23)	Byte 10 Force Data LO Coils (2 -31)	Byte 11 Error Check
04	00	00	[89][19]

Modbus message string:

[01] [0F] [00] [00] [20] [04] [3C] [04] [00] [00] [89] [19]

Stop Command: 0000010000111100 = 043C_{HEX} (reversed)
(see FC Protocol Control Word Bit Descriptions)

Speed Command: 0%

Message returned to Modbus master from Modbus RTU option card

Byte 0 Slave Address	Byte 1 Function	Byte 2 Coil Addr HI	Byte 3 Coil Addr LO	Byte 4 No. of Coils HI	Byte 5 No. of Coils LO	Byte 6 Error Check
01	0F	00	00	00	20	--

All values are in hexadecimal.

EXAMPLE THREE: Coast Stop Motor

Message sent to Modbus RTU option card from Modbus master

Byte 0 Slave Address	Byte 1 Function	Byte 2 Coil Addr HI	Byte 3 Coil Addr LO	Byte 4 # of Coils HI	Byte 5 # of Coils LO	Byte 6 Byte Count	Byte 7 Force Data HI Coils (0-7)
01	0F	00	00	00	20	04	20

Byte 8 Force Data LO Coils (8-15)	Byte 9 Force Data HI Coils (16-23)	Byte 10 Force Data LO Coils (24-31)	Byte 11 Error Chec
2C	00	00	--

Modbus message string:

[01] [0F] [00] [00] [20] [04] [20] [2C] [00] [00] [--]

Coast Command: 0010110000100000 = 2C20_{HEX} (reversed)
(see FC Protocol Control Word Bit Descriptions)

Speed Command: 0%

Message returned to Modbus master from Modbus RTU option card

Byte 0 Slave Address	Byte 1 Function	Byte 2 Coil Addr HI	Byte 3 Coil Addr LO	Byte 4 No. of Coils HI	Byte 5 No. of Coils LO	Byte 6 Error Check
01	0F	00	00	00	20	--



Message Translation Examples (continued)

EXAMPLE FOUR: Write Parameter 104, Motor Frequency, with 60 Hz (Data Type 6 – UINT16) (Conversion factor = 0)

Modbus Function 06_{HEX} *Preset Single Register*

Message sent to Modbus RTU option card from Modbus master

Byte 0 Slave Address	Byte 1 Function	Byte 2 Register Addr HI	Byte 3 Register Addr LO	Byte 4 Preset Data HI	Byte 5 Preset Data LO	Byte 6 Error Check
01	06	04	0F	00	3C	--

Modbus message string:

[01] 06] [04] [0F] [00] [3C] [error check]

Parameter 104 = 0F04_{HEX} (reversed)

Note that the starting address of a register is the parameter number x 10 -1 in HEX.

104 x 10 = 1040 -1 = 1039 = 0F04_{HEX} (reversed)

Modbus message string:

[01] 06] [04] [0F] [00] [3C] [error check]

Speed (60 Hz) = 3C_{HEX}

Message returned to Modbus master from Modbus RTU option card

Byte 0 Slave Address	Byte 1 Function	Byte 2 Register Addr HI	Byte 3 Register Addr LO	Byte 4 Preset Data HI	Byte 5 Preset Data LO	Byte 6 Error Check
01	06	04	0F	00	3C	--

All values are in hexadecimal.

EXAMPLE FIVE: Read Parameter 514, (Parameter 520 for VLT 5000) Motor Current = 3 Amps (Data Type 7 – UINT32) (Conversion Factor = -2)

Modbus Function 03_{HEX} *Read Holding Registers*

Message sent to Modbus RTU option card from Modbus master

Byte 0 Slave Address	Byte 1 Function	Byte 2 Start Addr HI	Byte 3 Start Addr LO	Byte 4 No. of Points HI	Byte 5 No. of Points LO	Byte 6 Error Chec
01	03	14	13	00	02	--

Parameter 514 (5139) = 1413_{HEX}

Message sent to Modbus master from Modbus RTU option card

Byte 0 Slave Address	Byte 1 Function	Byte 2 Byte Count	Byte 3 Data HI (Reg 45140)	Byte 4 Data LO (Reg 45140)	Byte 5 Data HI (Reg 45141)	Byte 6 Data LO (Reg 45141)	Byte 7 Error Check
01	03	04	00	00	01	2C	--

Message Translation Examples (continued)

EXAMPLE SIX: Write Parameter 533, Display Text 1, (VLT 6000 only) with “1234567890” (Data Type 9 – Text String).

Write IND with “0500” to perform a text write.

Modbus Function 06_{HEX} *Preset Single Register*

Message sent to Modbus RTU option card from Modbus master

Byte 0 Slave Address	Byte 1 Function	Byte 2 Register Addr HI	Byte 3 Register Addr LO	Byte 4 Preset Data HI	Byte 5 Preset Data LO	Byte 6 Error Check
01	06	00	00	05	00	--

Message sent to Modbus master from Modbus option card

Byte 0 Slave Address	Byte 1 Function	Byte 2 Register Addr HI	Byte 3 Register Addr LO	Byte 4 Preset Data HI	Byte 5 Preset Data LO	Byte 6 Error Check
01	06	00	00	05	00	--

Commands Modbus to text mode.

Modbus Function 10_{HEX} *Preset Multiple Registers*

Message sent to Modbus RTU option card from Modbus master

Byte 0 Slave Address	Byte 1 Function	Byte 2 Start Addr HI	Byte 3 Start Addr L	Byte 4 No. of Registers HI	Byte 5 No. of Registers LO	Byte 6 Byte Count	Byte 7 Data HI (Reg 414D2)
01	10	14	D1	00	05	0A	31

Byte 8 Data HI (Reg 414D2)	Byte 9 Data HI (Reg 414D3)	Byte 10 Data HI (Reg 414D3)	Byte 11 Data HI (Reg 414D4)	Byte 12 Data HI (Reg 414D4)	Byte 13 Data HI (Reg 414D5)	Byte 14 Data HI (Reg 414D5)	Byte 15 Data HI (Reg 414D6)
32	33	34	35	36	37	38	39

Byte 16 Data HI (Reg 414D6)	Byte 17 Error Check
30	--

Message sent to Modbus master from Modbus RTU option card

Byte 0 Slave Address	Byte 1 Function	Byte 2 Start Addr HI	Byte 3 Start Addr LO	Byte 4 No. Registers HI	Byte 5 No. Registers LO	Byte 6 Error Check
01	10	14	D1	00	05	--

All values are in hexadecimal.



Exception Codes

When the VLT responds to the master via the Modbus serial network, it uses the function code field to indicate either a normal (error-free) response or an error (called an exception response). In an error-free response, the drive simply echoes the original function code. For an exception response, the drive will return a code that is equivalent to the original function

code with its most-significant bit set to a logic 1. In addition, the drive places a unique code into the data field of the response message. This tells the master what kind of error occurred, or the reason for the exception. The tables below identify the codes and describe their meaning.

Modbus Code (decimal)	Meaning
00	The parameter number does not exist
01	There is no write access to the parameter
02	The data value exceeds the parameter limits
03	The used sub-index does not exist
04	The parameter is not of the array type
05	The data type does not match the parameter called
17	Data change in the parameter called is not possible in the present mode of the drive. Some parameters can only be changed when the motor has stopped
130	There is no bus access to the parameter called
131	Data Change is not possible because factory setup is selected
255	Message Timeout

VLT Errors

Modbus Code (decimal)	Meaning
64	Invalid Data Address
65	Invalid Message Length
66	Invalid Data Length
67	Invalid Function Code

Modbus Errors

APPENDIX A

Supported Modbus Function Codes

Appendix A describes the following functions supported by the Modbus RTU option card.

Read Coil Status (01_{HEX})
Force Single Coil (05_{HEX})
Force Multiple Coils (0F_{HEX})

Read Holding Registers (03_{HEX})
Preset Single Register (06_{HEX})
Preset Multiple Registers (10_{HEX})

Read Coil Status (01_{HEX})

Description

Reads the ON/OFF status of discrete outputs (OX references, coils) in the slave. Broadcast is never supported for reads.

Query

The query message specifies the starting coil and quantity of coils to be read. Coils are addressed starting at zero. Coils 1-16 are addressed as 0-15.

Example of a request to read coils 1-16 from slave device 01.

Field Name	Example (HEX)
Slave Address	01
Function	01
Starting Address HI	00
Starting Address LO	00
No. of Points HI	00
No. of Points LO	10
Error Check (CRC)	—

Response

The coil status in the response message is packed as one coil per bit of the data field. Status is indicated as: 1 = ON; 0 = OFF. The LSB of the first data byte contains the coil addressed in the query. The other coils follow toward the high order end of this byte, and from 'low order to high order' in subsequent bytes.

If the returned coil quantity is not a multiple of eight, the remaining bits in the final data byte will be padded with zeros (toward the high order end of the byte). The Byte Count field specifies the quantity of complete bytes of data.

Field Name	Example (HEX)
Slave Address	01
Function	01
Byte Count	02
Data (Coils 8-1)	55
Data (Coils 16-9)	AA
Error Check (CRC)	—



Force Single Coil (05_{HEX})

Description

Forces a single coil (0X reference) to either ON or OFF. When broadcast, the function forces the same coil references in all attached slaves.

Query

The query message specifies the coil reference to be forced. Coils are addressed starting at zero. Coil 1 is addressed as 0. Force Data = 00 00_{HEX} (OFF) or FF 00_{HEX} (ON).

Example of a request to set coil 1 (addressed as 0) from slave device 01.

Field Name	Example (HEX)
Slave Address	01
Function	05
Coil Address HI	00
Coil Address LO	00
Force Data HI	FF
Force Data LO	00
Error Check (CRC)	—

Response

The normal response is an echo of the query, returned after the coil state has been forced.

Field Name	Example (HEX)
Slave Address	01
Function	05
Force Data HI	FF
Force Data LO	00
Quantity of Coils HI	00
Quantity of Coils LO	0A
Error Check (CRC)	—

APPENDIX A

Force Multiple Coils (0F_{HEX})

Description

Forces each coil (0X reference) in a sequence of coils to either ON or OFF. When broadcast, the function forces the same coil references in all attached slaves.

Query

The query message specifies the coil references to be forced. Coils are addressed starting at zero. Coil 1 is addressed as 0.

Example of a request to set 10 coils starting at coil 1 (addressed as 0) from slave device 01.

Field Name	Example (HEX)
Slave Address	01
Function	0F
Coil Address HI	00
Coil Address LO	00
Quantity of Coils HI	00
Quantity of Coils LO	0A
Byte Count	02
Force Data HI (Coils 8-1)	FF
Force Data LO (Coils 10-9)	03
Error Check (CRC)	—

Response

The normal response returns the slave address, function code, starting address, and quantity of coils forced.

Field Name	Example (HEX)
Slave Address	01
Function	0F
Coil Address HI	00
Coil Address LO	00
Quantity of Coils HI	00
Quantity of Coils LO	0A
Error Check (CRC)	—

APPENDIX A



Read Holding Registers (03_{HEX})

Description

Reads the binary contents of holding registers (4x references) in the slave. Broadcast is never supported for reads.

Query

The query message specifies the starting register and quantity of registers to be read. Registers are addressed starting at zero. Registers 1-4 are addressed as 0-3.

Example of a request to read registers 40001-03 from slave device 01.

Field Name	Example (HEX)
Slave Address	01
Function	03
Starting Address HI	00
Starting Address LO	00
No. of Points HI	00
No. of Points LO	03
Error Check (CRC)	—

Response

The register data in the response message are packed as two bytes per register, with the binary contents right justified within each byte. For each register, the first byte contains the high order bits and the second contains the low order bits.

Field Name	Example (HEX)
Slave Address	01
Function	03
Byte Count	06
Data HI (Register 40001)	55
Data LO (Register 40001)	AA
Data HI (Register 40002)	55
Data LO (Register 40002)	AA
Data HI (Register 40003)	55
Data LO (Register 40003)	AA
Error Check (CRC)	—

APPENDIX A

Preset Single Register (06_{HEX})

Description

Presets a value into a single holding register (4x reference). When broadcast, the function presets the same register reference in all attached slaves.

Query

The query message specifies the register reference to be preset. Registers are addressed starting at zero. Register 1 is addressed as 0.

Example of a request to preset register 40002 to 00 03_{HEX} in slave device 01.

Field Name	Example (HEX)
Slave Address	01
Function	06
Register Address HI	00
Register Address LO	01
Preset Data HI	00
Preset Data LO	03
Error Check (CRC)	--

Response

The normal response is an echo of the query, returned after the register contents have been passed.

Field Name	Example (HEX)
Slave Address	01
Function	06
Register Address HI	00
Register Address LO	01
Preset Data HI	00
Preset Data LO	03
Error Check (CRC)	--

APPENDIX A



Preset Multiple Registers (10_{HEX})

Description

Presets values into a sequence of holding registers (4x references). When broadcast, the function presets the same register references in all attached slaves.

Query

The query message specifies the register references to be preset. Registers are addressed starting at zero. Register 1 is addressed as 0.

Example of a request to preset two registers starting at 40002 to 00 AA_{HEX} and 01 02_{HEX} in slave device 1.

Field Name	Example (HEX)
Slave Address	01
Function	10
Starting Address HI	00
Starting Address LO	01
No. of Registers HI	00
No. of Registers LO	02
Byte Count	04
Write Data HI (Register 40001)	00
Write Data LO (Register 40001)	0A
Write Data HI (Register 40002)	01
Write Data LO (Register 40002)	02
Error Check (CRC)	—

Response

The normal response returns the slave address, function code, starting address, and quantity of registers preset.

Field Name	Example (HEX)
Slave Address	01
Function	10
Starting Address HI	00
Starting Address LO	01
No. of Registers HI	00
No. of Registers LO	02
Error Check (CRC)	—

APPENDIX A

