Contents

Introduction

Safety
Safety Guidelines
Warnings Against Unintended Start
Introduction4
About this manual4
Assumptions4
References4
Trademarks5

Programming the VLT 6000

Control Panel5
Parameter Change Keys5
Local Control
Quick Menu6
To Enter or Change Quick Menu Parameter Data7
Example of Changing Parameter Data7
Extended Menu8
HP/kW

VLT 6000 Functional Features

Drive Operation	8
Motor and Drive Thermal Protection	8
Set-up 1-4	8
Current Monitoring and Limits	9
Direction of Rotation	9
Start/Stop	9
Freeze Mode	9
Coast	9
Motor Ramp-up and Ramp-down Rate	9
Lock Panel	9
Hand/Auto Modes	9
Run Enable	9
Bus Functions	9
Frequency Out High, Low Limits	9
Relay Out 1,2	9
PID Control Functions	10
Sleep Mode	10
Drive Control Display	10
Terminals	10
Faults, Warnings and Alarms	10
Error Status	10

VLT 6000 Network Strategies

Strategy One1	1
Strategy Two 1	1
Strategy Three13	3
Strategy Four13	3

Danfoss

VLT 6000 Special Functions

Safety Interlock	15
Analog Input Monitoring	15
Drive Relay Control	15

Network Connection

Hardware Setup16)
Electrical Control Terminals17	/
Typical Control Connection Examples18	3

VLT 6000 Functional Features

Startup of FLN Manual	20
Faults, Warnings and Alarms	20
Point Mapping Table	22
Point Mapping Table Notes	25
Point Database Definitions	26

Safety

Rotating shafts and electrical equipment can be hazardous. Therefore, it is strongly recommended that all electrical work conform to National Electrical Code (NEC) and all local regulations. Installation, start-up and maintenance should be performed only by qualified personnel.

Factory recommended procedures, included in this manual, should be followed. Always disconnect electrical power before working on the unit. Although shaft couplings or belt drives are generally not furnished by the manufacturer, rotating shafts, couplings and belts must be protected with securely mounted metal guards that are of sufficient thickness to provide protection against flying particles such as keys, bolts and coupling parts. Even when the motor is stopped, it should be considered "alive" as long as its controller is energized. Automatic circuits may start the motor at any time. Keep hands away from the output shaft until the motor has completely stopped and power is disconnected from the controller.

Motor control equipment and electronic controls are connected to hazardous line voltages. When servicing drives and electronic controls, there will be exposed components at or above line potential. Extreme care should be taken to protect against shock. Stand on an insulating pad and make it a habit to use only one hand when checking components. Always work with another person in case of an emergency. Disconnect power whenever possible to check controls or to perform maintenance. Be sure equipment is properly grounded. Wear safety glasses whenever working on electric control or rotating equipment.

Safety Guidelines

- 1. The drive must be disconnected from the AC line before any service work is done.
- 2. The "Stop/Off" key on the local control panel of the drive does not disconnect the equipment from the AC line and is not to be used as a safety switch.

- Correct protective grounding of the equipment must be established. The user must be protected against supply voltage and the motor must be protected against overload in accordance with applicable national and local regulations.
- 4. Ground currents are higher than 3 mA.

Warnings Against Unintended Start

- While the drive is connected to the AC line, the motor can be brought to a stop by means of external switch closures, serial bus commands or references. If personal safety considerations make it necessary to ensure that no unintended start occurs, these stops are not sufficient.
- 2. During programming of parameters, the motor may start. Be certain that no one is in the area of the motor or driven equipment when changing parameters.
- A motor that has been stopped may start unexpectedly if faults occur in the electronics of the drive, or if an overload, a fault in the supply AC line or a fault in the motor connection or other fault clears.
- If the "Local/Hand" key is activated, the motor can only be brought to a stop by means of the "Stop/Off" key or an external safety interlock

NOTE:

It is responsibility of user or person installing drive to provide proper grounding and branch circuit protection for incoming power and motor overload according to National Electrical Code (NEC) and local codes.

The Electronic Thermal Relay (ETR) in UL listed VLTs provides Class 20 motor overload protection in accordance with NEC in single motor applications, when parameter 117 is set for ETR TRIP 1, ETR TRIP 2, ETR TRIP 3, or ETR TRIP 4, and parameter 105 is set for rated motor (nameplate) current.

Dantoss

VLT[®] Adjustable Frequency Drive

ANGER:

Touching electrical parts may be fatal - even after equipment has been disconnected from AC line. To be sure that capacitors have fully discharged, wait 14 minutes after power has been removed before touching any internal component.

Introduction

The Siemens Floor Level Network (FLN) is a master/ slave control network for serial communication with various control devices. The FLN controller is RS-485 compatible, half duplex, with an operating rate of 4800 or 9600 baud. Recommended wiring is shielded, twisted pair. The FLN software protocol is designed to be general in nature to accommodate any unique properties of each device type. The node address system allows up to 96 devices to be used on any one system.

The Danfoss VLT 6000 is a programmable adjustable frequency drive which controls the operation of 3phase, standard induction electrical motors in the HVAC industry. The VLT 6000 controller has FLN communication protocol software built-in. The drive uses optical isolation for fault tolerance and noise immunity.

The FLN communicates directly with the VLT 6000 drive via the RS-485 serial interface bus. In addition to being able to control the drive, most drive configuration and control parameters can be reviewed and changed through the FLN. Also, the operational status of the drive can be read and monitored through the bus. Diagnostic and operational information stored in the VLT 6000 is easily available, such as kWh of energy used, total operation hours, drive status, motor speed, and many other useful items which can be accessed and monitored through the FLN.

The FLN is designed to communicate with any controller node that supports the interfaces defined in this document.

About This Manual

The documentation in this manual provides comprehensive information on the connection, programming, and start-up of the VLT 6000 for use with the FLN. It is intended as both an instruction and reference manual. Functions and features of the VLT 6000 adjustable frequency drive are also briefly reviewed to serve as a guideline to optimize your communication system. Read this manual before programming since important information is provided in each section.

For detailed information on using the VLT 6000, see the VLT 6000 Operating Instructions.

Assumptions

This manual assumes that the controller node supports the interfaces in this document and that all the requirements and limitations stipulated in the controller node and the VLT 6000 are strictly observed. It is assumed that the user understands the general capabilities and limitation of the controller node and the VLT 6000 adjustable frequency drive.

References

Installation, Operation and Maintenance Manual for the VLT[®] 6000 Adjustable Frequency Drive, Danfoss Graham document 23-6108-00. (Referred to as the VLT 6000 Operating Instructions in this manual.) Operating Instructions VLT 6000 HVAC Frequency Converter, Danfoss document MG.60.AX.YY

(International version of the VLT 6000 Operating Instructions.)

Contact Siemens for operational instructions for the Floor Level Network.

4

Trademarks

FLN[®] is a Siemens registered trademark. VLT[®] is a Danfoss registered trademark.

Programming the VLT 6000

The VLT 6000 adjustable frequency drive is delivered for installation and setup with the required application parameters already programmed at the factory. Specific motor nameplate data may have to be entered at the time of setup. The instructions in this section are intended to provide a general understanding of programming procedures and to enter Quick Menu setup data. See the *VLT 6000 Operating Instructions* for detailed information.



NOTE:

Quick menu data for commissioning drive cannot be entered via FLN serial bus.

Control Panel

The Local Control Panel (LCP), see Figure 1, is a complete interface for programming and operating the drive. The control panel can be removed from the drive and installed up to 3 meters (10 feet) away using the remote mounting kit.

The control panel has five functions:

- Display
- Keys for changing the display
- Keys for changing programming parameters
- Keys for controlling drive operation
- Indicator lamps

The LCP uses a four-line, alpha-numeric LCD display. The display can show four operating data values and three operating condition values continuously. During programming, all the information required for quick, effective parameter setup of the drive is displayed. All drive parameters can be changed from the control panel. Three lamps indicate power on (ON), warning (WARNING) and alarm (ALARM).

Parameter Change Keys

The LCP keys are divided into groups by function. The keys above indicator lamps are used for parameter setup, selecting the display indication during normal operation, and controlling the drive speed during local speed control operation. The keys below the indicator lamps are used for Start/Stop control, selection of the operating location, and reset.



Figure 1 VLT 6000 Keypad



The DISPLAY MODE key is used to change a display mode or to return to the Display Mode from either the Quick Menu or the Extend Menu mode.



The QUICK MENU key gives access to the parameters available for the Quick Menu setup. Parameters in this menu are the 12 most important setup parameters for the drive.



The EXTEND.MENU key gives access to all parameters.

CHANGE
DATA

The CHANGE DATA key is used for changing the value of a selected parameter. To change data, the desired parameter is first selected. The CHANGE DATA key is then pressed to enable editing of the parameter. An underline in the display will move under the parameter's value to show that it is being edited.

DANFOSS 17524544.10



The CANCEL key is used if a change of the selected parameter is not to be carried out.

The OK key is used to activate a change to the selected parameter.

The + and - keys are used to scroll through parameters and to increase or decrease the value of a chosen parameter. The keys are also used to change the local reference. In Display Mode, the keys are used to switch between readouts.

CANCEL

οк

The ◀ and ▶ keys are used to select a parameter group and also to move the cursor to the desired digit when changing numerical values.

Local Control

<u>Start signal via digital inputs may cause</u> <u>drive to start at any time. Remove power</u> <u>to drive before working on output wiring,</u> <u>motor or any driven equipment.</u>

Below the indicator lamps on the LCP are keys used to determine control of the drive. Each key can be individually enabled or disabled using parameters 012 through 015. The Hand Start and Auto Start keys are disabled if any of the control terminals are programmed for either Remote Hand or Remote Auto.



The HAND START key is used to start the drive from the control panel. Pressing HAND START issues a start command to the drive.

A lf a minimum speed is set in parameter 201, Output Frequency Low Limit, motor will start and ramp up to this frequency when HAND START key is pressed. If drive is already running in Auto Mode when HAND START is pressed, drive will begin running in Hand Mode and in local control. OFF STOP The OFF/STOP key is used for stopping the connected motor in either the Hand or Auto Mode. Enable or disable this function via parameter 013, *OFF/START on LCP*. If this stop function is activated, the second line in the LCD display will flash.



AUTO START is used if the drive is to be started via FLN serial communication and/or the digital control terminals. When a remote start signal is received, the drive will start if the AUTO START key has been pressed.

NOTE:

AUTO START key must be pressed to enable starting drive from FLN serial bus or remote terminals.



RESET is used for manually resetting the drive after an alarm (fault trip). In this case, the top line of the display shows TRIP (RESET). If the top line of the display shows TRIP (AUTO START), the drive will automatically restart. If the top line of the display shows TRIPLOCK (DICS.MAINS), input power to the drive must be removed before the trip can be reset.

Quick Menu

The QUICK MENU key gives access to 12 of the most important setup parameters of the drive. After Quick Menu programming, in many cases the drive will be ready for operation. The 12 Quick Menu parameters are shown in Table 1. Refer to the *VLT 6000 Operating Instructions* for a complete description of the functions.

Quick Menu Item Number	Parameter Name	Description
1	001 Language	Selects language used for all displays.
2	102 Motor Power	Sets output characteristics of drive based on kW (HP) of motor. See Table 2 to convert HP to kW.
3	103 Motor Voltage	Sets output characteristics of drive based on voltage of motor.
4	104 Motor Frequency	Sets output characteristics of drive based on nominal frequency of motor. This is typically equal to line frequency.
5	105 Motor Current	Sets output characteristics of drive based on full load current in amps (FLA) of motor. This sets overload protection for motor.
6	106 Motor Nominal Speed	Sets output characteristics of drive based on nominal full load speed of motor.
7	201 Minimum Frequency	Sets minimum controlled frequency at which motor will run.
8	202 Maximum Frequency	Sets maximum controlled frequency at which motor will run.
9	206 Ramp Up Time	Sets time to accelerate motor from 0 Hz to nominal motor frequency set in Quick Menu Item 4.
10	207 Ramp Down Time	Sets time to decelerate motor from nominal motor frequency set in Quick Menu Item 4 to 0 Hz.
11	323 Relay 1 Function	Sets function of high voltage Form C relay.
12	326 Relay 2 Function	Sets function of low voltage Form A relay.

Table 1 Quick Menu Items Description



During programming of parameters, motor may start. Be certain no one is in area of motor or driven equipment when

To Enter or Change Quick Menu Parameter Data

Enter or change parameter data or settings in accordance with the following procedure.

- 1. Press Quick Menu key.
- 2. Use '+' and '-' keys to find parameter you chose to edit.
- 3. Press Change Data key.
- 4. Use '+' and '-' keys to select correct parameter setting. To move to a different digit within parameter, use \blacktriangleleft and \triangleright arrows. Flashing underline indicates digit selected to change.

- 5. Press Cancel key to disregard change, or press OK key to accept change and enter new setting.
- Press Display key to return to normal display. 6.

Example of Changing Parameter Data

Assume parameter 206, Ramp Up Time, is set at 60 seconds. Change the ramp up time to 100 seconds in accordance with the following procedure.

- 1. Press Quick Menu key.
- 2. Press "+" key until you reach Parameter 206, Ramp Up Time.
- 3. Press Change Data key.
- 4. Press ◀ key twice – hundreds digit will flash.
- Press "+" key once to change hundreds digit 5. to '1.'
- 6. Press ► key once to move cursor to tens digit.



VLT[®] Adjustable Frequency Drive

- 7. Press "-" key until '6' counts down to '0' and setting for Ramp Up Time reads '100 s.'
- 8. Press OK key to enter new value into drive controller.
- Press Display key to return to normal display. 9.

Extended Menu

In some applications, the Quick Menu items will not set up all the desired characteristics of the drive. To access all VLT 6000 parameters, including the Quick Menu parameters, press the Extend Menu key.



NOTE:

Programming of parameter functions available through Extended Menu is done in accordance with same procedure as described for Quick Menu functions.

HP/kW Conversion

A conversion index for determining kW and HP ratings is shown in Table 2.

Table 2 HP to kW Conversion Index

kW	HP	kW	HP
0.25	0.33	45	60
0.37	0.5	55	75
0.55	0.75	75	100
0.75	1.0	90	125
1.1	1.5	110	150
1.5	2.0	132	175
2.2	3.0	160	200
3.0		200	300
4.0	5.0	250	
5.5	7.5	300	
7.5	10	315	350
11	15	355	450
15	20	400	500
18.5	25	450	600
22	30		
30	40		
37	50		

VLT 6000 Functional Features

The FLN protocol built into the VLT 6000 adjustable frequency drive allows programming of numerous features and monitoring of the drive via the serial bus and the standard RS-485 port. The VLT 6000 also has the capability to control closed or open loop systems on its own and has been designed specifically for HVAC applications. Always accessible in real-time are the system status, what the motor and drive are doing, and if there are any problems. The VLT 6000 continuously monitors all aspects of motor and drive status and issues alarms or warnings for adverse conditions.

The FLN interacts with the drive based upon a point map database and the selected interface strategy. Many, but not all, drive features are accessible through the point map. See the VLT 6000 Operating Instructions for more drive details. Table 8 lists the map points and Table 9 supplies definitions. Below is a review of some frequently used drive features and the associated point map numbers.

Drive Operation (03-14)

These points provide the FLN with operational status information such as output frequency, motor current, output voltage, power and energy. The run time in hours that power has been supplied to the motor is also stored for display, along with cumulative energy used in kWh.

Motor and Drive Thermal Protection (15, 16, 18) The motor and drive are protected against thermal overload. The percentage of thermal load is displayed. Point 18 indicates if either the motor or drive thermal limit has been exceeded.

Set-up 1 - 4 (17) (29)

The drive is capable of maintaining four independent program set-ups. Each set-up supports independent point map configurations. Seasonal changes, various acceleration or deceleration rates, or other operation modes can be accommodated. Point 17 indicates which setup is active. The set-up change is programmed through the drive's keypad or digital I/ Os. Day/night operation is implemented in the point map (29) but is not used in this application.

Current Monitoring and Limits (19, 30)

The maximum current that the drive provides to the motor can be limited. This tends to limit the torgue that can be produced by the motor. Data point 30 sets the current limit in amps, while data point 19 indicates if the motor is operating at that current limit.

Direction of Rotation (21-22)

The drive responds to serial commands to reverse direction of the motor. The drive can safely reverse motor rotation while in operation. Many applications benefit from this ability, such as vane axial fans reversed for smoke extraction or cooling towers for deicing. Parameter 506, *Reversing*, must be set to serial communication for point 22 to command the feature.

Start/Stop (23, 24)

To run the drive from the FLN or in Auto mode from the drive's digital control terminals, a start command must be given at data point 24. When a stop command is given at this point, the drive will only run in Hand mode.

Freeze Mode (25, 26)

If desired, the frequency of the drive can be frozen at its present value. The mode is indicated by data point 25. It is an option available when serial interface is lost.

Coast (27, 28)

The coast command (28) shuts down the inverter and makes the motor freewheeling, which normally brings it to stand still. The drive cannot be restarted in any mode before the coast command is removed. It is, therefore, often used as a safety interlock. Data point 27 indicates when the drive is coasted.

Motor Ramp-up and Ramp-down Rate (31, 32)

The time to accelerate or decelerate the drive between 0 Hz and the motor's nominal frequency can be programmed. The drive is capable of settings between one to 3600 seconds (one hour).

Lock Panel (33)

The local control panel on the VLT 6000 drive can be locked to ensure that program data or drive control functions cannot be changed locally. The Stop button on the keypad will also be locked out and be incapable of stopping the drive. The serial interface continues to access drive settings.

Hand/Auto Modes (34)

The SEL HND.AUTO shows which mode the drive is in. The drive can be commanded into either Hand or Auto mode by pressing the respective keys on the keypad of the drive. Hand mode disables any programmed control strategies and allows the drive keypad to be used to set the drive speed. The only serial communication command that can override Hand mode is data point 28, CMD COAST.

Run Enable (35)

Set data point 35 to ON to run the drive from the FLN with default drive parameter settings. In the OFF mode, the drive will run only in Hand mode or in Auto mode from the drive's digital control terminals. Parameter 505, *Start*, controls the interaction of point 35 and the digital run command.

Bus Functions (36, 37)

The amount of time the drive will wait between communication packets is programmable. If the time is exceeded, the drive will assume serial communication has stopped and respond with programmable choices. The drive can ignore the loss, freeze its current output, stop, run at a predetermined jog frequency, run at maximum output frequency or stop and trip while issuing an alarm. Wait time is selected at point 36 and the function after a timeout at point 37. See descriptions for parameters 565, *FLN Bus Time Interval* and 566, *FLN Bus Time Interval Function* in the *VLT 6000 Operating Instructions*.

Frequency Out High, Low Limits (38, 39)

Limits to the maximum and minimum drive output frequency are programmable. For example, pump manufacturers typically recommend not to operate pumps below a certain speed (for example, 15 Hz) to avoid seal problems.

Relay Out 1, 2 (40, 41, 43, 44)

Two programmable relay outputs (one Form C, 240 VAC, 2 Amp; and one Form A, 30 VAC, 1 Amp) are available. These can be triggered through the serial bus by command points 40 and 41. This allows the FLN to utilize the drive's built-in relays as additional network programmable relays. The data points 43 and 44 indicate whether the relay is triggered or not (On/Off). Parameters 323 and 326, *Relay 1* and *Relay 2 Output Function*, must be set to CONTROL WORD 11/12.

Danfoss

PID Control Functions (42, 61-65, 68-74) The VLT 6000 has a sophisticated built-in proportional, integral, derivative (PID) controller. The PID controller is activated by setting parameter 100, *Configuration*, to *Closed loop* through the drive's keypad.

The PID controller in the VLT 6000 supports two feedback values and two setpoints. The feedback can be received in the form of network bus signals and/or standard 0-10 V transmitters. The 2 setpoint controller is capable of controlling return fans based on a fixed differential flow, secondary pumping systems, and so on. This can be used to supplement the BMS system to save on points or capacity. For details on use of the two feedback/ setpoint feature, refer to the *VLT 6000 Operating Instructions*. Data points 43 and 44 show the status of an FLN command to the drive.

The points PI GAIN and PI TIME are gain parameters similar to the P and I gains in the FLN TECs. The Danfoss PI loop is structured differently than the Siemens loop, so there is not a one-to-one correspondence between the gains. The following formulas allow translation between Danfoss and Siemens gains.

Converting from Danfoss PI gains to Siemens P and I gains:



Converting from Siemens P and I gains to Danfoss PI gains:

PI GAIN _{DANFOSS} = P GAIN _{SIEMENS} * 667 PI TIME _{DANFOSS} = $\frac{P GAIN}{I GAIN}$ _{SIEMENS}

Sleep Mode (54-59)

Sleep mode automatically stops the drive when demand is low over a period of time. When the system demand increases, the drive restarts the motor to reach the desired output. Sleep mode has great energy savings potential and saves wear and tear on equipment. Unlike a setback timer, the drive is always available to run when a preset "wakeup" demand is reached. See parameters 403 through 406 in the *VLT 6000 Operating Instructions* for more detail.

Drive Control Display (80-86)

The operational status of the drive is readily available on the FLN serial interface bus. The drive displays various states including ready to start, waiting for run enable, run, fault reset and stop.

Terminals 53, 54, 60 (87-89)

Two analog voltage input terminals 53 and 54 (0 to 10 VDC) and one analog current terminal 60 (0 to 20 mA) are provided for reference or feedback signals. The applied electrical signal can be read by data points 87 to 89 in volts and mA. This can be very useful during commissioning to calibrate transmitters. This can also be used to convert any other analog transmitter in the installation into a digital bus signal, even if the signal is not used by the drive. In this case, the input terminal should be programmed to *No Function* so it does not to influence the drive's operation.

Faults, Warnings and Alarms (90-94)

The drive displays a warning or tripped by a fault condition. It also can retrieve the last warning or fault trip for display. The drive can be reset through the FLN serial bus to resume normal drive operation.

Error Status (99)

Data point 99 is implemented in the point map but is not used in this application.



VLT[®] Adjustable Frequency Drive

VLT 6000 Network Strategies

The VLT 6000 drive has its own internal PID closed loop controller. This can be turned on or off. depending on the requirements of the control strategy. A brief summary of possibilities follows. This is meant to illustrate possibilities rather than be allinclusive. An actual application may combine features from a more than one of these strategies.

Strategy One

FLN Function - Monitor drive operation

VLT 6000 Control - From a conventional, hardwired system

VLT 6000 Mode - Open Loop

The VLT 6000 follows hard-wired run/stop signals. An external, hard-wired PID controller provides the drive with a speed reference signal. The FLN monitors the operation of the drive without control function.

Network Inputs to the VLT 6000: Because the FLN is simply monitoring the operation of the drive, it provides no inputs.

Network Outputs from the VLT 6000: The

following points are monitored by the FLN to indicate system status. This list could be expanded or shortened, depending on the requirements of the system.

- 03 FREQ OUTPUT
- 08 POWER
- 10 KWH
- 23 STOP.RUN
- 92 OK.FAULT

Strategy Two

FLN Function - Control all aspects of drive operation

VLT 6000 Control - From FLN

VLT 6000 Mode - Open Loop

The VLT 6000 follows run/stop and speed reference signals from the FLN. The FLN receives the feedback signal from the controlled system, compares this to a setpoint value, and uses its own PID control loop to determine the required drive speed.

Network Inputs to the VLT 6000:

The following drive points might be controlled by the FLN.

Speed Command:

53 BUS REF - This is the speed reference command. This is set as a percentage of the drive's reference range, determined by VLT 6000 parameters 204, Minimum Reference, and 205, Maximum Reference. Setting point 53 to 0 gives the drive a reference command equal to the value stored in parameter 204. Setting point 53 to 16384 gives the drive a reference command equal to the value stored in parameter 205.Intermediate values for point 53 change the reference linearly between these two values.



NOTE:

In general, any other reference signal is added to the bus reference. Disable all other drivereference inputs when using a bus reference to control drive speed.

Example 1: In a pumping application, the minimum frequency (point 38 or parameter 201) is set to 18 Hz, and the maximum frequency (point 39 or parameter 202) is set to 60 Hz. You want to command the drive's speed with a 0 - 100% signal, where 0% commands 18 Hz and 100% commands 60 Hz. To unbundle the bus reference (point 53) for commanding in percent:

- Set minimum reference (point 50 or 1. parameter 204) to 18 Hz, the minimum frequency.
- 2. Set maximum reference (point 51 or parameter 205) to 60 Hz, the maximum frequency.
- 3. Intercept = 0 (since the minimum reference value is 0).
- 4. Slope can be calculated as follows:

slope = (DesiredRange)×(Slope of ExistingPoint) Range of ExistingPoint

 $\frac{100 \times 1}{16384}$

= 0.0061

NOTE:

Although range listed for point 53 is 32767, that represents a 200% speed command. Since a 100% speed command is desired here, half of value 32767 is used for range of existing point.

Example 2: In a pumping application, the minimum frequency (point 38 or parameter 201) is set to 18 Hz, and the maximum frequency (point 39 or parameter 202) is set to 60 Hz. You want to command the drive's speed with a 0 – 100% signal, where 0% commands 0 Hz and 100% commands 60 Hz. Because the minimum frequency is 30% of maximum speed, speed refe-rence commands from 0 to 30% will cause the drive to run at minimum speed, 18 Hz.

To unbundle the bus reference (point 53) for commanding in percent:

- 1. Set minimum reference (point 50 or parameter 204) to 0 Hz.
- 2. Set maximum reference (point 51 or parameter 205) to 60 Hz, the maximum frequency.
- 3. Intercept = 0 (since the minimum reference value is 0)
- 4. Slope can be calculated as follows:

slope = (DesiredRange)×(Slope of ExistingPoint) Range of ExistingPoint

$$=\frac{100 \times 1}{16384}$$

= 0.0061

Although the action of the reference signal is different in examples 1 and 2, the unbundled reference is the same. This is due to programming minimum and maximum reference values in the drive.

Start/Stop Command: To give a start command from the FLN, the following points must be set. The VLT 6000 can also respond to discrete run/stop control signals that are hard wired to its control terminals. The point used to stop the drive through the FLN determines the capability of these discrete command signals.

- 28 CMD COAST In most cases, it is necessary to set this point to NO to make the drive run. If this is set to COAST while the VLT 6000 is running, the drive will shut off immediately and the motor will coast to a stop. When set to COAST, the lower right corner of the drive display shows UN. READY (unit ready). The drive will not start in either HAND mode or through discrete control signals until point 28 is set to NO. VLT 6000 parameter 503, *Coasting*, can defeat this. See the *VLT 6000 Operating Instructions* for details. Because point 28 can keep the drive from operating in any mode, this is commonly
- 24 CMD STP.STRT It is necessary the set this point to START to make the drive run. If this is set to STOP while the drive is running, the drive will decelerate to a stop. When this is set to STOP, the drive cannot be started using a hardwired discrete run command. It can, however, be started in HAND mode from the keypad.

used to provide a safety interlock function.

35 RUN ENABLE – In most cases, it is necessary to set this point ON to make the drive run. If this is set to OFF while the drive is running, the drive will decelerate to a stop. When set to OFF, the lower right corner of the display shows STAND BY. When OFF, the drive can be started in HAND mode from the keypad. It can also be started using a hardwired discrete run command, as when parameter 505, *Start*, is set to digital input.



VLT[®] Adjustable Frequency Drive

Network Outputs from the VLT 6000:

The points listed in Strategy One are commonly used.

Strategy Three

FLN Function - Monitor drive operation

VLT 6000 Control – From a hard-wired system, including system feedback

VLT 6000 Mode – Closed Loop The VLT 6000 follows hard-wired run/stop signals.The drive uses its internal PID controller to control motor speed. The feedback signal is hard wired to the VLT 6000 analog input and the setpoint is programmed into the drive. The FLN is used to monitor the status of the drive and the value of the VLT 6000 PID controller setpoint and feedback.

Network Inputs to the VLT 6000: Because the FLN is simply monitoring the operation of the drive, it provides no inputs.

Network Outputs from the VLT 6000: In addition to the points listed in Strategy One, it may be useful to monitor the following points related to the operation of the VLT 6000 PID controller.

Feedback:

- **60 INPUT REF** This is the setpoint for the VLT 6000 PID controller in units defined in parameter 415, *Units Relating to Closed Loop.*
- **62 PI FEEDBACK** This is the value of the feedback signal for the VLT 6000 PID controller in the units defined in parameter 415.

Strategy Four

FLN Function – Provide the drive with setpoint and feedback values using the VLT 6000 PID controller to determine motor speed

VLT 6000 Control - From the FLN

VLT 6000 Mode - Closed Loop

The VLT 6000 follows run/stop signals from the FLN. The FLN receives the feedback signal from the controlled system. It sends this and the desired setpoint to the VLT 6000 PID controller. The drive compares the feedback signal with the setpoint and adjusts the speed of the drive accordingly.

Network Inputs to the VLT 6000: In addition to

start/stop control, which was discussed in Strategy Two, the FLN provides the drive with feedback and setpoint information using the following points.

Feedback:

- **71 FB MIN** The VLT 6000 can display the PID controller's setpoint and feedback signal in units chosen in drive parameter 415, *Units Relating to Closed Loop.* The value that the minimum feedback signal represents can be set using either point 71 or drive parameter 413, *Minimum* Feedback.
- **72 FB MAX** The VLT 6000 can display the PID controller's setpoint and feedback signal in units chosen in drive parameter 415. The value that the maximum feedback signal represents can be set using either point 72 or drive parameter 414, *Maximum Feedback*.
- **73 BUS FB 1** A value of 0 represents the minimum feedback signal, as defined by point 71 or parameter 413. A value of 16383 represents the maximum feedback signal, as defined by point 72 or parameter 414. This should be the feedback used if only one feedback signal is supplied to the drive.

NOTE:

If drive terminal 53 is programmed in parameter 308, *Analog Inputs*, for feedback, any signal applied to terminal 53 is added to value provided at point 73. Therefore, it is generally advisable not to program parameter 308 for feedback.

74 BUS FB 2 - This is used when two feedback signals are supplied to the drive PID controller. VLT 6000 parameter 417, *Feedback Function*, determines the the function that the drive applies to these signals. Functions include minimum, maximum, sum, difference, and average. A value of 0 represents the minimum feedback signal, as defined by point 71 or

Danfoss

parameter 413. A value of 16383 represents the maximum feedback signal, as defined by point 72 or parameter 414. See the *VLT 6000 Operating In Istructions* for details.

NOTE:

If drive terminal 54 is programmed in parameter 311, *Analog Inputs*, for feedback, any signal applied to terminal 54 is added to value provided at point 73. Therefore, it is generally advisable not to program parameter 311 for feedback.

Example: In a cooling tower application, the feedback signal comes from a temperature sensor with a range of 40°F to 140°F. To unbundle bus feedback 2 (point 74) for the temperature sensor:

- 1. Set minimum feedback (point 71 or parameter 413) to 40.
- Set maximum feedback (point 72 or parameter 414) 140.
- 3. Intercept = 40 (since the minimum feedback value is 40)
- 4. Slope can be calculated as follows:

 $slope = \frac{(Desired Range) \times (Slope of ExistingPoint)}{Range of ExistingPoint}$

 $=\frac{(140-40)\times0.1}{16383}$

= 0.00061

Setpoint:

- **50 REF MIN** The VLT 6000 can display the PID controller's setpoint and feedback signal in units. The units displayed are chosen in drive parameter 415. The value that the minimum reference signal represents can be set using either point 50 or drive parameter 204.

- **69 SETPOINT 1** This is the PID controller's setpoint, expressed in the units that were chosen in parameter 415. It can be set to any value between REF MIN (point 50 or parameter 204) and REF MAX (point 51 or parameter 205). If an attempt is made to set point 69 to a value outside of this range, the setpoint will not be changed. SETPOINT 1 can also be programmed using parameter 418, *Setpoint 1.*
- **70** SETPOINT 2 This PID controller setpoint is used for applications where two feedback signals will be compared to independent setpoints. Refer to the *VLT 6000 Operating Instructions* for more details.
 SETPOINT 2 is expressed in the units selected in parameter 415. It can be set to any value between REF MIN (point 50 or parameter 204) and REF MAX (point 51 or parameter 205). If an attempt is made to assign point 70 to a value outside of this range, the setpoint will not change.
 SETPOINT 2 can also be programmed using parameter 419, *Setpoint 2*.

PID Controller Adjustments:

The following points adjust the operation of the VLT 6000 PID control loop. They are generally set during start-up and only adjusted if changes in the system require it. these values can also be set using parameters. See the *VLT 6000 Operating Instructions* for more details.

- 61 PI START FREQ (parameter 422) This sets the frequency to which the drivewill accelerate after a start command. After it reaches this frequency, the drive will activate its PID controller. Point 61 can have a value between the drive's minimum frequency (as set in parameter 201) and its maximum frequency (as set in parameter 202). If an attempt is made to set point 61 to a value outside of this range, the drive value will not change.
- **63 PI GAIN** (parameter 423) This sets the value of proportional gain for the VLT 6000 PID controller. It can have a value between 0 and 10.



VLT[®] Adjustable Frequency Drive

- 64 PI I TIME (parameter 424) This sets the integral time for the VLT 6000 PID controller. It can have a value between 0.01 seconds and 9999 (OFF). In order for the controller to function properly, this should not be rned off.
- **65 PI GAIN LIMIT** (parameter 426) This sets the maximum derivative gain for the VLT 6000 PID controller. It can have a value between 5 and 50.
- 66 LOWPASS FLTR (parameter 427) This sets the time constant for the noise filter in the VLT 6000 PID controller feedback loop. It can have values between 0.01 and 10 seconds.
- **68 FB FUNCTION** (parameter 417) This sets how the VLT 6000 PID controller responds to the drive's two feedback signals. Its value is an integer between 0 and 6. Refer to the VLT 6000 Operating Instructions for the list of choices and an explanation of each.

Network Outputs from the VLT 6000: The points listed in Strategy One are commonly used.

■ VLT 6000 Special Functions

In addition to the control strategies described above, the VLT 6000 provides additional control flexibility to allow it to integrate into special control systemrequirements. The following are just a few examples.

Safety Interlock:

The VLT 6000 can accept a safety interlock stop command that is hard-wired to the drive control terminals and another from the FLN. When VLT 6000 parameter 304, *Digital Inputs*, is set to SAFETY INTERLOCK, an open hard-wired safety interlock will cause the drive to display ALARM 60 EXTERNAL FAULT. Setting point 28 to COAST will display UN. READY in the lower right corner of the drive's display. The individual displays for each allow the operator to determine which device caused the trip. VLT 6000 parameter 503, *Coasting Stop*, determines the interaction of these two safety interlocks. See the *VLT 6000 Operating Instructions* for details.

Analog Input Monitoring:

Points 87, 88 and 89 can be used to monitor the value of the analog control signals applied to terminals 53, 54 and 60. These points are active even when NO FUNCTION is programmed for the analog input of the drive. As a result, it is possible to use the VLT 6000 analog inputs as analog input for the FLN.

Drive Relay Control:

While relay 1 and 2 in the VLT 6000 usually provide drive status indications, these indications are generally not needed when the drive is connected to an FLN. In some applications, it can be useful to have the FLN control these relays. For example, by controlling one of the relays, the FLN could select the active pump in a pump sequencing system. For the FLN to control a drive relay, the appropriate VLT 6000 parameter (323 or 326) must be set to CONTROL WORD 11/12. Setting point 40 or 41 to ON will then activate the corresponding relay.

Network Connection

Connect the VLT 6000 to the FLN in accordance with the following procedure (see Figure 2).

- Connect signal wires to terminal 68 (P+) and terminal 69 (N-) on main control board of drive. (See tightening torque and wire size in Table 3.)
- 2. If shielded cabling is used, connect one end of shield to terminal 61. This terminal is connected to ground via an internal RC link.

NOTE:



It is recommended to use shielded, twistedpair cables to reduce noise between conductors.

Table 3	Tightening	Torque and	Wire Gage
---------	------------	------------	-----------

Torque Specs	4.5 in lb/0.5 Nm
Control wire	18 –24 AWG, shielded, twisted pair/1.5 mm, shielded twisted pair





Figure 2 Network Terminal Connection

Hardware Setup

A terminator dip switch on the main control board of the VLT 6000 is used to configure the drives on the FLN bus. It is used for serial communication and to connect and disconnect the drive's digital inputs from the drive's internal DC power supply. The switch positions shown in Figure 3 demonstrate the factory setting. Table 4 lists the switch functions and settings required for FLN operation.





Switch	Setting
Switch 1	No function
Switches 2 & 3	Used for terminating an RS-485 interface. On first and last devices in a multiple device network, or on the only device in a single device network, switches 2 and 3 must be ON . On all other devices in a multiple device network, 2 and 3 must be OFF .
Switch 4	Separates the common of the internal 24 VDC power supply from the common of the digital inputs. Normally this switch is ON and the power supply is present at terminals 12 and 13 for digital inputs. When OFF, the negative of an external power supply is connected to terminal 20 and the positive output is used to turn on the desired digital inputs (terminals 16, 17, 18, 19, 27, 29, 32, and 33).

Table 4. Terminator Switch Functions and FLIN Setting	Table 4.	Terminator	Switch	Functions	and	FLN	Settings
---	----------	------------	--------	-----------	-----	-----	----------

NOTE:

Terminator switch positions must be set correctly in accordance with Table 4 for proper FLN serial communacation.

Electrical Control Terminals

In most cases, the VLT 6000 will have electrical control connections (see Figure 4) already connected at equipment installation. The functional description of the drive's electrical control terminals in Table 5 are provided primarily for system modification and expansion. Two examples of typical

serial interface control connections are demonstrated in Figures 5 and 6. Many of these terminals have multiple functions that are determined by drive parameter settings. See the *VLT 6000 Operating Instructions* for detailed information.

Table 5 Electrical Control Terminals Functional Description

Number	Function
01, 02, 03	Form C relay output. Maximum 240 VAC, 2 A. Minimum 24 VDC, 10 mA or 24 VAC, 100 mA. (Terminal group 01, 02, and 03 is placed in various locations on the power side of the drive, depending upon the model type.)
04, 05	30 VAC, 42.5 VDC, 1 Amp relay outputs can be used for indicating status and warnings.
12, 13	Voltage supply to digital inputs and external transducers. For the 24 VDC to be used for digital inputs, switch 4 on the control card must be closed (position on). The maximum output current is 200 mA.
16 - 33	Digital inputs. R = 2 kohm
	<5 V = logical "0"
	>10 V = logical "1"
16 - 33	30 VAC, 42.5 VDC, 1 A relay output can be used for indicating status and warnings.
20	Voltage supply to digital inputs and external transducers. For the 24 VDC to be used for digital inputs, switch 4 on the control card must be closed (position on). The maximum output current is 200 mA.
39	Digital inputs. R = 2 kohm. <5 V = logical "0", >10 V = logical "1"
42, 45	Analog and digital outputs for indicating frequency, reference, current and torque. The analog signal is 0 to 20 mA, or 4 to 20 mA at a maximum of 500 ?. The digital signal is 24 VDC at a minimum of 600 ?.
50	10 VDC, 17 mA maximum analog supply voltage to potentiometer and thermistor.
53, 54	0 to 10 VDC voltage input, R = 10 ?.
55	Common for analog inputs. This common is isolated from the common of all other power supplies. If, for example, the drive's 24 VDC power supply is used to power an external transducer which provides an analog input signal, terminal 55 must be wired to terminal 39.
60	0 to 20 mA or 4 to 20 mA, analog current input, R = 188 ? .
61	Shield for serial communication.
68, 69	RS-485 interface and serial communication. When the drive is connected to an RS-485 serial communication bus, DIP switches 2 and 3 must be closed on the first and the last device in the serial connection. On the remaining drives, switches 2 and 3 must be open. The factory setting is closed (position on).



DANFOSS 175HA379.10



Typical Control Connection Examples

Transmitter Connection:

The drive's internal 24 VDC power supply is used to power an external 4 to 20 mA transducer (see Figure 5).





Set Parameter 314, *Terminal 60, Analog Input Current*, to correspond to the purpose of the 4 to 20 mA signal.

Set Parameter 315, *Terminal 60, Min. Scaling*, to 4 mA. Set Parameter 316, *Terminal 60, Max. Scaling*, to 20 mA.

Because the commons of the +24 VDC power supply and the input reference follower have separate circuit commons, it is necessary to connect a jumper between terminals 39 and 55.

Two Feedback Signals:

The drive processes two independent feedback signals during closed loop operation (see Figure 6). It can respond to the sum, difference, average, minimum or maximum of these signals.





Set Parameter 308, *Terminal 53, Analog Input Voltage*, to FEEDBACK. Set Parameter 311, *Terminal 54, Analog Input Voltage*, to FEEDBACK

Set Parameter 417, *Feedback Function*, for the desired operation.



Parameter Settings

The VLT 6000 has a unique FLN address which is transmitted over the RS-485 serial bus. The network will recognize the drive, which may then be programmed for setup options. The parameters listed in Table 6 need to be set for each drive on the FLN network. FLN communication related parameters can only be set through the LCP keypad.



NOTE:

As a minimum, it is required to set parameter 500, Protocol, to FLN; parameter 501, Address, to the proper address; and parameter 502, Baud Rate, to the proper baud rate. (See Programming the VLT 6000 in this manual.)

Parameters 503 through 508 are options that select control of the drive through the digital and/or the FLN serial port. Parameter 565, FLN Time Interval, and 566, FLN Time Interval Function, can be commanded by the data points 36 and 37 (see Table 9).

Parameter	Description	Default	Desired setting
*500	Protocol	FC	FLN
*501	Address	1	1 through 98
*502	Baud Rate	9600	4800 or 9600
**503	Coasting	Logic or	
**504	DC-brake	Logic or	
**505	Start	Logic or	
**506	Reversing	Digital	
**507	Selection of setup	Logic or	
**508	Selection of preset ref.	Logic or	
565	FLN Time Interval	60 sec	1 - 65534 sec
566	FLN Time Interval Function	Off	

Table 6 VLT 6000 Parameter Settings

* Minimum parameters which must be set to operate the VLT 6000 via FLN serial interface.

** When Digital input or Logic or is selected, digital inputs may interfere with serial bus commands. The setting Serial communication allows serial bus commands only to be carried out. See the VLT 6000 Operating Instructions for detailed descriptions.



Dantoss

Startup of FLN Control

This procedure assumes that the VLT 6000 adjustable frequency drive has been installed properly and is operational in Hand control mode. It also assumes the Siemens FLN data bus is connected to an operational controller. Start the VLT 6000 in accordance with the following procedure.

- 1. Ensure that the assumptions in this procedure are correct.
- 2. Check that the network connections are securely fastened in accordance with Figure 2.



Verify compliance with all safety requirements listed in this manual.

- 3. Apply power to the VLT 6000.
- 4. Ensure that the minimum settings listed in Table 6 are selected.
- 5. Ensure that the switch positions in Figure 3 are set correctly.
- 6. Optional settings may be changed to meet or enhance the drive's operation, depending on the application requirements.
- For FLN control of the drive, press the AUTO START key on the VLT 6000 LCP keypad. Drive operation can then be controlled through the host network device in accordance with its operation instructions.



Faults, Warnings and Alarms

DANGER: <u>A stopped motor may start unexpectedly</u> <u>if faults occur in electronics of drive, or if</u> <u>fault clears, such as a fault in supply AC</u> <u>line, or fault in motor connection, or overload.</u>

The VLT 6000 adjustable frequency drive outputs faults, warnings and alarms on the FLN serial bus in a numerical code. The code numbers are described in Table 7. The Reset key is used for manually resetting the drive after an alarm (fault trip). In this case, the top line of the display will show TRIP (RESET). If the top line of the display shows TRIP (AUTO START), the drive will automatically restart. If the top line of the display shows TRIPLOCK (DISC. MAINS), input power to the drive must be cycled off and on again before the trip can be reset.

Refer to the *VLT 6000 Operating Instructions* for detailed descriptions.



Fault	Description	Warning	Alarm		
number			Trip ¹⁾	Trip Lock ²⁾	
1	10 volts low	Х			
2	Live zero	Х	Х		
4	AC power failure	Х	Х	Х	
5	DC link voltage high	Х			
6	DC link voltage low	Х			
7	Over voltage	Х	Х		
8	Under voltage	Х	Х		
9	Inverter time	Х	Х		
10	Motor time	Х	Х		
11	Motor thermistor	Х	Х		
12	Current limit	Х	Х		
13	Over current		Х	Х	
14	Ground fault		Х	Х	
15	Switch mode fault		Х	Х	
16	Current short circuit		Х	Х	
17	Serial comm. timeout	Х	Х		
18	HPFB timeout	Х	Х		
19	EEPROM on power card	Х			
20	EEPROM on control card	Х			
22	AMA fault		Х		
29	Heat sink temperature too high		Х	Х	
30	Motor phase U missing		Х		
31	Motor phase V missing		Х		
32	Motor phase W missing		Х		
34	HPFB comm. fault	Х	Х		
37	Inverter fault		Х	Х	
39	AMA check par. 104, 106	Х			
40	AMA check par. 103, 105	Х			
41	AMA motor too big	Х			
42	AMA motor too small	Х			
60	External fault		Х		
61	Output frequency low	Х			
62	Output frequency high	Х			
63	Output current low	Х	Х		
64	Output current high	Х			
65	Feedback low	Х			
66	Feedback high	Х			
67	Reference low	Х			
68	Reference high	Х			
69	Thermal Auto derating	Х			
99	Unknown alarm		Х	X	

Table 7 Faults, Warnings and Alarms Description

Trip: Requires a reset, either manual or automatic, depending on the the setting of parameter 400, *Reset Function*.
 Trip lock: Requires AC power cycled on and off and a reset.

Alarms that also have a corresponding warning cannot be reset until warning has been removed, i.e., fault situation is gone. Points 90-91 refer to warnings. Points 92-94 refer to alarms.

Danfoss

Point Mapping Table

The VLT 6000 parameters, along with the internal variables and readouts for controlling the drive via the FLN serial bus, are organized as a Point Map. Not all parameters and readouts are supported by the FLN protocol. FLN points 01, 02, 20, 29 and 99

are predefined. Available points and a description of their characteristics are listed in Table 8. Parameters which can be written to ("W" in the Read/Write column) are programmable through the FLN device, others ("R") are read-only, or read and write ("R/W").

Table 8 Point Mapping

Point Number	Descriptor	Factory Default (SI Units)	SI Units	Slope (SI Units)	Intercept (SI Units)	Range	On Text	Off Text	Read/ Write	Param. number	Network Port Type Note 1
01	CTLR ADDRESS	1		1	0	255			R	501	Pre- defined
02	APPLICATION	2709		1	0	255			R		Pre- defined
Readout Points											
{03}	FREQ OUTPUT	0	HZ	0.1	0	16383			R	512	LAI
{06}	CURRENT	0	А	0.1	0	16383			R	514	LAI
{08}	POWER	0	KW	1	0	511			R	515	LAI
{10}	KWH	0	KWH	3.1	0	32767			R	602	LAI
{12}	RUN TIME	0	HRS	4.0	0	32767			R	601	LAI
{13}	DC BUS VOLT	0	VOLTS	1	0	1023			R	518	LAI
{14}	OUTPUT VOLT	0	VOLTS	1	0	1023			R	517	LAI
{15}	MOTOR THERM	0	PCT	1	0	255			R	519	LAI
{16}	DRIVE THERM	0	PCT	1	0	255			R	520	LAI
{17}	CURR. SETUP	0		1	0	255			R		LAI
{18}	TIMERS STAT	0					LIMIT	ОК	R	527-15	LDI
{19}	CURRENT STAT	0					LIMIT	ОК	R	527-14	LDI
20	OVRD TIME	1	HRS	1	0	255			W		Pre- defined
				Status and	Command F	Points					
{21}	FWD.REV	FWD					REV	FWD	R	532-8	LDI
{22}	CMD FWD.REV	FWD					REV	FWD	W	Cmd-15	LDO
{23}	STOP.RUN	STOP					RUN	STOP	R	527-11	LDI
{24}	CMD STP.STRT	STOP					START	STOP	W	Cmd-4	LDO
{25}	FREEZE OUT	NO					FREEZE	NO	R	532-16	LDI
{26}	CMD FREEZE	FREEZE					NO	FREEZE	W	Cmd-5	LDO
{27}	COAST	COAST					NO	COAST	R	530-3	LDI
{28}	CMD COAST	COAST					NO	COAST	W	Cmd-3	LDO
				Common Co	nfiguration	Points					
29	DAY.NIGHT Note 2	DAY				255	NIGHT	DAY	W		Pre- defined
{30}	CURRENT LIM Note 3	Note 4	A	0.1	0.1	16383			W	215	LAO
{31}	ACCEL TIME 1	Note 4	SEC	1	1	4095			R/W	206	LAO
{32}	DECEL TIME 1	Note 4	SEC	1	1	4095			R/W	207	LAO

MG.60.G1.02 - VLT is a registered Danfoss Trademark

Danfoss

Point Number	Descriptor	Factory Default (SI Units)	SI Units	Slope (SI Units)	Intercept (SI Units)	Range	On Text	Off Text	Read/ Write	Param. number	Network Port Type Note 1
{33}	LOCK PANEL Note 5	OPEN					LOCK	OPEN	R/W	12-15	LDO
{34}	SEL HND.AUTO	HAND					AUTO	HAND	R	532-13	LDI
{35}	RUN ENABLE	OFF					ON	OFF	W	Cmd-6	LDO
{36}	BUS TIME	60	SEC	2	2	32767			R/W	565	LAO
{37}	BUSTIME FUNC	0 Note 6		1	0	255			R/W	566	LAO
{38}	F OUT LOW Note 3	0	HZ	0.1	0	16383			W	201	LAO
{39}	F OUT HIGH Note 3	Note 4	HZ	0.1	0	16383			W	202	LAO
				Physical	Output Poir	nts					
{40}	RELAY OUT 1	OFF					ON	OFF	W	Cmd-11	LDO
{41}	RELAY OUT 2	OFF					ON	OFF	W	Cmd-12	LDO
{42}	PI STRT FR.S	0	HZ	0.1	0	16383			R	422	LAI
{43}	RELAY 1 STAT	OFF					ON	OFF	R	530-11	LDI
{44}	RELAY 1 STAT	OFF					ON	OFF	R	530-12	LDI
{45}	CURR. LIM.S	Note 4	А	0.1	0.1	16383			R	215	LAI
{46}	F OUT LOW.S	0	HZ	0.1	0	16383			R	201	LAI
{47}	F OUT HIGH.S	Note 4	HZ	0.1	0	16383			R	202	LAI
{48}	REF MIN.S	0	UNIT	0.1	-1638.3	32767			R	204	LAI
{49}	REF MAX.S	Note 4	UNIT	0.1	-1638.3	32767			R	205	LAI
				Setpoint	Related Poi	nts					
{50}	REF MIN Note 3	0	UNIT	0.1	-1638.3	32767			W	204	LAO
{51}	REF MAX Note 3	Note 4	UNIT	0.1	-1638.3	32767			W	205	LAO
{52}	REF STAT	OFFREF					ON.REF	OFFREF	R	527-8	LDI
{53}	BUS REF	0		1	0	32767 Note 7			R/W		LAO
{54}	SLEEP FREQ.S	0	HZ	0.1	0	16383			R	404	LAI
{55}	WAKEUP FRQ.S	Note 4	HZ	0.1	0	16383			R	405	LAI
{56}	SLEEP TIME	301	SEC	1	0	511			R	403	LAI
{57}	SLEEP FREQ Note 3	0	HZ	0.1	0	16383			W	404	LAO
{58}	WAKEUP FREQ Note 3	Note 4	HZ	0.1	0	16383			W	405	LAO
{59}	SLEEP MODE	OFF					SLEEP	OFF	R	532-3	LDI
				PI Loop I	Related Poi	nts					
{60}	INPUT REF	0	UNIT	0.1	-1638.3	32767			R	510	LAI
{61}	PI STRT FREQ Note 3	0	HZ	0.1	0	16383			W	422	LAO
{62}	PI FEEDBACK	0	UNIT	0.1	-1638.3	32767			R	511	LAI
{63}	PI GAIN	0.3		0.01	0	1023			R/W	423	LAO
{64}	PI I TIME	9999	SEC	0.3051543	0.01	32767			R/W	424	LAO



Point Number	Descriptor	Factory Default (SI Units)	SI Units	Slope (SI Units)	Intercept (SI Units)	Range	On Text	Off Text	Read/ Write	Param. number	Network Port Type Note 1
{65}	PI GAIN LIM	5		0.1	0	511			R/W	426	LAO
{66}	LOWPASS FLTR	0.01	SEC	0.01	0	1023			R/W	427	LAO
{67}	SLEEP BOOST	OFF					BOOST	OFF	R	532-2	LDI
{68}	FB FUNC	1		1	0	255			R/W	417	LAO
		Note 6									
{69}	SETPOINT 1 Note 3	0	UNIT	0.1	-1638.3	32767	-		W	418	LAO
{70}	SETPOINT 2 Note 3	0	UNIT	0.1	-1638.3	32767			W	419	LAO
{71}	FB MIN Note 3	0	UNIT	0.1	-1638.3	32767		1	W	413	LAO
{72}	FB MAX Note 3	100.0	UNIT	0.1	-1638.3	32767			W	414	LAO
{73}	BUS FB 1	0		1	0	16383			R/W	535	LAO
{74}	BUS FB 2	0		1	0	16383	-		R/W	536	LAO
	-	- -		Miscella	neous Poir	nts			-	-	
{75}	AUTO RAMP	OFF					ACTIVE	OFF	R	532-0	LDI
{76}	VOLT STAT	ОК					LIMIT	ОК	R	527-13	LDI
{77}	INVERT STAT	OK					STALL	ОК	R	527-12	LDI
{78}	FREQ STAT	OUTRNG					IN.RNG	OUTRNG	R	527-10	LDI
{79}	CTRL STAT	LOCAL					BUS	LOCAL	R	527-9	LDI
{80}	DRV ENA STAT	NOTENA					ENABLE	NOTENA	R	527-2	LDI
{81}	DRV RDY STAT	NOTRDY					READY	NOTRDY	R	527-1	LDI
{82}	DRVCTRL STAT	NOTRDY					READY	NOTRDY	R	527-0	LDI
{84}	RESET	NO					RESET	NO	R	530-7	LDI
{85}	START	OFF					ON	OFF	R	530-6	LDI
{86}	Q.STOP	Q.STOP					NO	Q.STOP	R	530-4	LDI
{87}	TERM 53	0	VOLTS	0.1	0	255			R	522	LAI
{88}	TERM 54	0	VOLTS	0.1	0	255			R	523	LAI
{89}	TERM 60	0	MILAMP	0.1	0	255			R	524	LAI
	ſ			Error R	elated Poin	ts			-		
{90}	OK.WARNING	ОК					WARN	OK	R	527-7	LDI
{91}	LAST WARNING	0 Note 8		1	0	255			R		LAI
{92}	OK.FAULT	ОК					FAULT	OK	R	527-3	LDI
{93}	LAST FAULT	0 Note 8		1	0	255			R	615	LAI
{94}	RESET FAULT	NO					RESET	NO	W		LDO
{95}	SETPOINT 1.S	0	UNIT	0.1	-1638.3	32767			R	418	LAI
{96}	SETPOINT 2.S	0	UNIT	0.1	-1638.3	32767			R	419	LAI
{97}	FB MIN.S	0	UNIT	0.1	-1638.3	32767			R	413	LAI
{98}	FB MAX.S	100.0	UNIT	0.1	-1638.3	32767			R	414	LAI
99	ERROR STATUS Note 2	0		1	0	255			R		Pre- defined



Point Mapping Table Notes:

Point numbers that appear in brackets { } may be unbundled at the field panel.

- Note 1: LAI stands for "Logical Analog Input." This is an analog value that the VLT 6000 provides to the FLN network. Itsvalue is a feedback indicating the status of a physical input to the drive.
 LAO stands for "Logical Analog Output." This is an analog output from the FLN network to the VLT 6000. It is used to control the operation of the drive.
 LDI stands for "Logical Digital Input." This is a digital (ON/OFF) signal from the VLT 6000 to the FLN network. It indicates the operation of the drive.
 LDO stands for "Logical Digital Output." This is a digital (ON/OFF) signal from the FLN network to the VLT 6000. It is used to control or indicate the operation of the drive.
- Note 2: Points 29 and 99 are present but not used in this application.
- **Note 3:** These points will accept any value within the range of the point even though the drive has different upper and/or lower limits for these points. This is because the upper and lower limits for these points can vary depending on settings of other points or the drive size. Consult the *VLT 6000 Operating Instructions* for values.

Twelve special read-only points can be used for checking if the value actually changed or the change was rejected. These 12 read-only points should also be used for monitoring database COVs which the others cannot. The read-only points are designated by a descriptor similar to the original point with a suffix ".S" added.

Below is a list of pairing where the points in parenthesis are the read-only points: 30 (45), 38 (46), 39 (47), 50 (48), 51 (49), 57 (54), 58 (55), 61 (42), 69 (95), 70 (96), 71 (97), 72 (98).

- **Note 4:** The default value depends on the drive. Consult the *VLT 6000 Operating Instructions* for values.
- **Note 5:** When LOCK PANEL is set to LOCK, the "Hand Start", "Off Stop", "Auto Start" and "Reset" keys on the VLT 6000 keypad will be disabled. Four parameters in the drive will change simultaneously. Local programming of the drive will also be locked except for parameter 016, *Lock for Data Change*, which can disable the programming lock.
- **Note 6:** Consult the *VLT 6000 Operating Instructions* for choice options.
- Note 7: The number 32767 equals 200% of Bus Ref range value.
- **Note 8:** Use Table 7, *Faults, Warnings and Alarms*, to determine the FAULT or WARNING corresponding to a number.



Point Database Definitions

 Table 9
 Point Database Definitions

Point Number	Descriptor	Definition
01	CTLR ADDRESS	Predefined device address.
02	APPLICATION	Predefined FLN application for use with VLT 6000 drive.
03	FREQ OUTPUT	Displays drive speed in hertz.
06	CURRENT	Displays drive output current in amps.
08	POWER	Displays drive power output in kilowatts.
10	KWH	Displays drive cumulative energy output in kilowatt-hours.
12	RUNTIME	Displays number of hours drive has supplied power to motor.
13	DC BUS VOLT	Displays drive voltage at DC bus in DC volts.
14	OUTPUTVOLT	Displays output voltage to motor in AC volts.
15	MOTOR THERM	Displays motor thermal load in percentage.
16	DRIVETHERM	Displays drive thermal load in percentage.
17	CURR. SETUP	Displays parameter setup number currently controlling drive.
18	TIMERS STAT	Displays if temperature limit of motor, drive or motor thermistor has been exceeded.
19	CURRENT STAT	Displays if drive is operating in current limit.
20	OVRDTIME	Not used.
21	FWD.REV	Displays direction of motor rotation, forward or reverse.
22	CMD FWD.REV	Commands direction of motor rotation.
23	STOP.RUN	Displays drive RUN/STOP status.
24	CMD STP.STRT	Commands drive to start or stop.
25	FREEZE OUT	Displays if output frequency is in freeze mode at present value.
26	CMD FREEZE	Commands drive to freeze present output frequency.
27	COAST	Displays if drive has been given a coast to stop command.
28	CMD COAST	Commands drive to make motor coast to a stop.
29	DAY.NIGHT	Selects day or night mode. (Has no effect on drive operation.)
30	CURRENT LIM	Sets maximum drive output current to motor in amps.
31	ACCELTIME 1	Sets motor ramp up time in seconds.
32	DECELTIME 1	Sets motor ramp down time in seconds.
33	LOCK PANEL	Used to lock out Hand Start, Off/Start, Auto Start and Reset keys on LCP.
34	SEL HAND.AUTO	Displays operation in Hand or Auto control mode function.
35	RUN ENABLE	Used to enable or disable drive operation in auto mode.
36	BUSTIME	Sets time limit to determine loss of serial communication in seconds.
37	BUSTIME FUNC	Selects drive response to loss of serial communication.
38	F OUT LOW	Sets minimum drive output frequency.
39	F OUT HIGH	Sets maximum drive output frequency.
40	RELAY OUT 1	Controls drive relay output 1. Note: Set relay output to corresponding function.
41	RELAY OUT 2	Controls drive relay output 2. Note: Set relay output to corresponding function.
42	PI STRT FR.S	Displays status of point 61.
43	RELAY 1 STAT	Displays status of FLN command to drive relay output 1.
44	RELAY 2 STAT	Displays status of FLN command to drive relay output 2.
45	CURR. LIM.S	Displays status of point 30.
46	F OUT LOW.S	Displays status of point 38.
47	F OUT HIGH.S	Displays status of point 39.
48	REF MIN.S	Displays status of point 50.
49	REF MAX.S	Displays status of point 51.
50	REFMIN	Sets lowest frequency reference value for drive.
51	REFMAX	Sets highest frequency reference value for drive.
52	REF STAT	Displays if drive is running at commanded reference.

Danfoss

VLT® Adjustable Frequency Drive

Point Number	Descriptor	Definition
53	BUS REF	Sends drive an external reference signal in percent.
54	SLEEP FREQ.S	Displays status of point 57.
55	WAKEUP FREQ.S	Displays status of point 58.
56	SLEEP TIME	Displays run time at low speed before sleep mode starts.
57	SLEEP FREQ	Sets output frequency required to activate sleep mode timer.
58	WAKEUP FREQ	Sets command frequency required to restart motor after sleep mode.
59	SLEEP MODE	Displays when drive is stopped in sleep mode.
60	INPUT REF	Displays drive input reference in Hz or as selected in parameter 415.
61	PI STRT FREQ	Sets drive frequency after start at which PID control is activated.
62	PI FEEDBACK	Displays resulting feedback value in units selected in parameter 415.
63	PI GAIN	Sets proportional gain of PID controller in percentage.
64	PITIME	Sets integral time of PID controller in seconds.
65	PI GAIN LIM	Sets maximum gain for differentiator of PID controller.
66	LOWPASS FILTER	Sets lowpass filter time constant for feedback circuit.
67	SLEEP BOOST	Displays sleep boost set point in percentage.
68	FBFUNC	Selects calculation method when two feedback signals are used.
69	SETPOINT 1	Sets setpoint for feedback 1 in units selected in parameter 415.
70	SETPOINT 2	Sets setpoint for feedback 2 in units selected in parameter 415.
71	FBMIN	Sets minimum feedback signal value in units selected in parameter 415.
72	FB MAX	Sets maximum feedback signal value in units selected in parameter 415.
73	BUS FB 1	Supplies feedback value for bus feedback 1 in percent.
	BUS FB 2	Supplies feedback value for bus feedback 2 in percent.
75	AUTO RAMP	Displays when drive deceleration rate is extended due to auto ramping.
76	VOLT STAT	Displays if drive DC bus voltage exceeds high/low warning limits.
77	INVERT STAT	Displays drive inverter status, ok or stall.
78	FREQISTAT	Displays if drive is running outside of frequency limits of parameters 223 and 224.
		Displays whether drive is in local control or FLN serial bus.
80		Displays if drive is enabled to start when run command given.
81		Displays it drive control is ready or it a trip has occurred.
82		Displays drive control status as ready or not ready.
84	KESEI	Displays if a fault reset command has been given via serial bus.
65		Displays if a run command has been given via serial bus.
00		Displays if a stop command has been given via senar bus.
07		Displays voltage value of signal on terminal 55 in volts.
80		Displays voltage value of signal on terminal 60 in mA
00		Displays current value of signal of terminal of in mA.
91		Displays a drive is in a warning condition.
92		Displays last drive warning.
93		Displays last drive fault trip
94	RESET FAULT	Resets drive faults and resumes normal drive operation
95	SETPOINT 1.S	Displays status of point 69.
96	SETPOINT 2.S	Displays status of point 70.
97	FB MIN.S	Displays status of point 71.
98	FB MAX.S	Displays status of point 72.
99	ERROR STATUS	Not used.